

***NOWFOREVER***

**A100 Series Inverter**  
**User Manual**  
**V1.6**

SHENZHEN NOWFOREVER ELECTRONICS TECHNOLOGY CO.,LTD.

# Contents

Inspection.....	1
Sofeware updated description .....	2
<b>1 Safety Precautions.....</b>	<b>4</b>
1.1 Safety Items.....	4
1.2 Notice Items.....	7
<b>2 Summarize.....</b>	<b>11</b>
2.1 Description of Nameplate.....	11
2.2 Production Information.....	11
2.3 Selection Guide.....	12
2.3.1 220V Series Description .....	12
2.3.2 380V Series Description .....	13
2.4 Technology Criterion.....	14
2.5 Functions.....	16
2.6 DC reactor Options Description.....	17
2.7 Braking Resistor Selection Guide.....	17
2.8 Braking Resistor wiring Description.....	18
2.1 The wiring Description at the signal board of injection machine.....	19
<b>3 Installation.....</b>	<b>21</b>
3.1 Installation Environment.....	21
3.2 Installation Direction and Space.....	21
3.3 Installation dimensions of Inverter.....	22
<b>4 Wiring .....</b>	<b>26</b>
4.1 Connection of Periperal devices.....	26

4.2	Typical Wiring Diagram.....	27
4.2.1	Wiring Diagram .....	27
4.2.1	Terminal configuration .....	29
4.3	Description of Control Circuit Terminals.....	30
4.3.1	Control Circuit Terminal Layout .....	31
4.3.2	Description of Control Circuit Terminals.....	31
4.3.3	Wiring Description on Control Circuit Terminals .....	33
4.3.4	Jumpers and interface on control board.....	35
<b>5</b>	<b>Operation.....</b>	<b>37</b>
5.1	Keypad Description.....	37
5.1.1	Keypad schematic diagram .....	37
5.1.2	Key function description .....	37
5.1.3	Indicator light description .....	38
5.1.4	Digital display .....	39
5.2	Operation process.....	39
5.2.1	Fast-monitoring .....	40
5.2.2	Function codes setting .....	40
5.2.3	Information Query .....	41
5.2.4	Fault Alarm Reset .....	41
5.2.5	Keyboard digital setting modify rapid.....	41
5.3	Motor parameter autotuning.....	41
5.4	Quick debugging.....	42
<b>6</b>	<b>Detailed Function description .....</b>	<b>44</b>
6.1	P0 Group—Basic Function.....	44
6.1.1	Basic Function .....	44
6.1.2	Motor Parameters .....	49
6.1.3	V/F Curve Parameter .....	50

6.1.4	VVVF Control Parameter .....	52
6.1.5	Vector control parameter .....	53
6.1.6	Input terminals .....	54
6.1.7	Output terminals .....	59
6.1.8	Start and Stop Control .....	61
6.1.9	Acc/Dec assistant .....	64
6.1.10	Auxiliary function .....	65
6.1.11	Keyboard setting .....	68
6.1.12	Protect function setting .....	69
6.1.13	Multi-step speed and simple PLC .....	73
6.1.14	PID control .....	77
6.1.15	Traverse frequency setting .....	80
6.1.16	Serial Communication Settings .....	81
6.1.17	Counter 、timer function .....	82
6.1.18	Reserved for function group .....	83
6.1.19	Function Code modify setting .....	85
6.2	PI function groups (supplier setting function code)	86
6.3	d0 function groups (read only) .....	86
<b>7</b>	<b>Fault and trouble shooting .....</b>	<b>87</b>
7.1	Fault and alarm.....	87
7.1.1	Fault Indication and Fault Reset .....	87
7.1.2	Alarm indication and alarm reset .....	87
7.2	Fault and trouble shooting.....	87
7.3	Common faults and solutions.....	89
7.3.1	No display after power on: .....	89
7.3.2	Motor doesn' t move after inverter running...	90
<b>8</b>	<b>Maintenance.....</b>	<b>91</b>
8.1	Inspect the inverter periodically.....	91

8.2 Replacement of wearing parts.....	91
8.3 Warranty description.....	92
<b>9 List of Function Parameters .....</b>	<b>93</b>
9.1 P0 function groups (users setup function code) ....	93
9.2 P1 function groups (supplier setting function code) .....	108
9.3 d0 function groups (fault information of history)	108
9.4 d1 function groups (inverter information) .....	109
9.5 d2 function groups (Inverter running state) .....	110
9.6 d3 function groups (users interface state) .....	111
<b>10 MODBUS Communication Protocol .....</b>	<b>113</b>
10.1 MODBUS Communication Modes.....	113
10.2 Information format.....	113
10.3 Examples of MODBUS Information.....	115
10.3.1 To read the contents of storage register...	115
10.3.2 Test circuit .....	116
10.3.3 Write into multi-storage register .....	116
10.3.4 Data saved instruction .....	117
10.3.5 Broadcast model sent data .....	117
10.4 Inverter for slave.....	117
10.4.1 Instruction Data .....	118
10.4.2 Monitoring Data .....	118
10.4.3 Set Data .....	118
10.4.4 Test Data .....	119
10.5 Inverter for master.....	119
10.6 MODBUS Communication Error Codes.....	119
10.7 Back-check of no response fault for slave .....	120
<b>Chart Index.....</b>	<b>121</b>

## **Inspection**

Don't install or use any inverter that is damaged or have fault part, otherwise may cause injury.

Check the following items when unpacking the inverter,

1. Ensure there is operation manual and warranty card in the packing box.
2. Inspect the entire exterior of the Inverter to ensure there are no scratches or other damage caused by the transportation.
3. Inspect the nameplate and ensure it is what you ordered.
4. Ensure the optional parts are what you need if have ordered any optional parts.

Please contact the local agent if there is any damage in the inverter or optional parts

## Software updated description

x809 software upgraded on the basis of the x806.

x809 software includes two versions: 0809 corresponds to 380V class inverter, 1809 corresponds to 220V class inverter .

Distinguish Items	x806 Software	x809 Software
P0-003 Main frequency source<x>choice	Setting range:0~8	Setting range:0~10 Increase the VCI input mode 2,When the segment-speed terminal in effect, switch to the multi-segment-speed mode immediately. Increase the CCI input mode 2, when the segment-speed terminal in effect, switch to a multi-speed mode immediately.
P0-004 Assistant frequency source<Y>choice		
P0-014 Carrier frequency	Setting range: 2.0 ~ 10.0KHz	Setting range:1.0~10.0KHz, Carrier can be set to 1k.
P0-117 Default Monitoring Parameters	Setting range: 0~12	Setting range:0~13 When parking was increased, the set frequency is displayed; running, the output frequency is displayed.
P0-170 PID channel selection for a given	Setting range: 0~6	Setting range:0~7 Increase in CCI input , a given method on 4 ~ 20mA current .
P0-172 PID Feedback channel selection	Setting range: 0~4	Setting range:0~6 Increase 4 ~ 20mA current-feedback mode in CCI input.Increase the VCI-CCI feedback mode to achieve difference temperature control.
P0-184 Local address	Setting range: 1~32	Setting range:1~254 Address numbers increased to 254
P0-195 AO1 output Bias	Without this function	You can set the minimum output value, meet the P0-077 can achieve 4 ~ 20mA Output (P0-077=0.8, P0-195=2.00) .

## Software updated description

Distinguish Items	x806 Software	x809 Software
P0-196 AO2 output Bias	Without this function	You can set the minimum output value, meet the P0-078 can achieve 4 ~ 20mA Output (P0-078=0.8, P0-196=2.00)
P0-197 Minimum input of keypad potentiometer	Without this function	When the setting value of keyboard can not be regulated to 0hz, to increase the value.
P0-198 Maximum input of keypad potentiometer	Without this function	When the setting value of keyboard can not be regulated to 50hz ,to reduce the value.
P0-199 filter coefficient of keypad potentiometer	Without this function	When the setting value of keyboard wave, increase the value.
P0-200 VCI Input Bias	Without this function	Adjust the input bias on the VCI analog input channel .
P0-201 CCI Input Bias	Without this function	Adjust the input bias on the CCI analog input channel .



# 1 Safety Precautions

## Safety Definition

In this manual, the safety precautions were sorted to “Danger” or “Caution”



Indicates a potentially dangerous situation which, if can not avoid will result in death or serious injury.



Indicates a potentially dangerous situation which, if can not avoid will cause minor or moderate injury and damage the device. This Symbol is also used for warning any un-safety operation.

## 1. 1 Safety Items

**Before installation :**



1. Please don't use the inverter of being scathed or loss of parts!
2. Please use insulating motor upwards B class, otherwise will result in death or serious injury on account of getting an electric shock!

**When installation:**



Please install the inverter on the fireproofing material (such as metal) to prevent fire.



1. When need install two or more inverters in one cabinet, cooling fan should be provided to make sure that the air temperature is lower than 45°C. Otherwise it could cause fire or damage the device.

2. When moving the inverter please lift by its base and don't lift by the panel. Otherwise may cause the main unit fall off which may result in personal injury.

**When wiring:**



1. Wiring must be performed by the person certified in electrical work!
2. Inverter and power must be comparted by breaker, otherwise the firing will be caused!
3. Cannot install the inverter until discharged completely after the power supply is switched off for 5 minutes.
4. Be sure to ground the ground terminal!



1. Connect input terminals (R, S, T) and output terminals (U, V, W) correctly.  
Otherwise it will cause damage the inside part of inverter!
2. To ensure the wiring according with EMC requirements and safety standards in the region, the wire diameter used reference the manual suggested, or might be an accident!
3. Brake resistor can not be directly connected between “DC bus +” to “DC bus-” terminals, or may cause a fire!

**Before power-on:**



1. Please confirm whether the power and voltage level is consistent with the rated voltage of the converter, input and output wiring position is correct or not, and pay attention to check whether there are short-circuit in the external circuit phenomenon, insure the line is fastened, otherwise the inverter may cause damage!

2. Inverter cover must be covered in the pre-power, otherwise may cause an electric shock!



1. Inverters do not need to do pressure test, factory products have made this test, factory products have been made this test, otherwise it might cause an accident!
2. All the external parts is connected exactly in accordance with this manual , or may cause an accident!

**After power-on:**



1. Do not open the lid after power-on, otherwise there is a risk of electric shock!
2. Do not wire and operate the inverter with wet hands. Otherwise there is a risk of electric shock!
3. Do not touch inverter terminals (including the control terminal), otherwise there is a risk of electric shock!
4. Just power-on, the inverter can carry out safety testing for external strong electric circuit automatically, this time, please do not touch the U, V, W terminals or motor terminals, otherwise there is a risk of electric shock!



1. If the need for parameter identification, please note that the risk of injuries in motor rotation, otherwise may cause an accident!
2. Please do not arbitrarily change the parameters of inverter manufacturers, otherwise may result in equipment damage!

**Run state:**



1. When the user selects the function re-starting, please do not close to the mechanical equipment, otherwise may cause personal injury!
2. Do not touch the cooling fan and discharge resistance in order to test the temperature, otherwise it might cause burn!
3. To detect the signal must be performed by the person certified in electrical work, otherwise may cause personal injury or equipment damage!



1. Inverter is running, please avoid the sundries fall into the device, otherwise it would cause equipment damage!
2. Please do not use this method of contactor on and off to control the converter's start-stop, otherwise it would cause equipment damage!

**When maintaining:**



1. Never service and maintain the inverter with electrification, May cause injury or electric shock.
2. When power off, should not maintain the inverter until after 5 minutes, which can ensure the device discharge completely.
3. The person without passing the speciality training, Don't is permitted to operate and maintain this equipment, otherwise will cause severe injury or property loss.

**1.2 Notice Items**

1. Before using this motor at first a long time not being used and regular inspection, should do insulation inspection for the motor, to prevent damaging to the inverter due to the motor winding insulation failure. be sure to separate the electrical connection from the inverter when the insulation inspection, ensure to use 500V voltage model megger. Should

ensure the measured insulation resistance is no less than 5 megohm.

2. Thermal protection of the motor

If the selection of motor and rated capacity of the inverter does not match, especially when rated power of the inverter bigger than rated power of the motor, be sure to adjust the motor protection-related parameters in the inverter or pre-installed in the motor thermal relay for motor protection.

3. Running the above Work-frequency

The inverter can provide 0Hz ~ 600Hz output frequency, if the customer need to run at 50Hz and above, consider the affordability of mechanical devices. Please consider the affordability of mechanical devices.

4. The vibration of mechanical devices

When the output frequency to achieve certain values of the inverter, you may encounter a mechanical resonance point of the load devices. It can be avoided by setting the parameters of the frequency jump in inverter.

5. Regarding motor heat and noise

Because output voltage of the inverter is the PWM wave, contains some harmonics wave, Therefore, the motor temperature rise, noise and vibration compared to the Work-frequency in running will be a slight increase.

6. Have pressure-sensitive parts or improving the capacitance of power factor on output side ,Inverter output is a PWM wave, the capacitors to improve the power factor has been installed at the output side or pressure-sensitive resistance for lightning strike protection, etc. .Can easily lead to transient currents and even damage to the inside part of inverter ,please do not use.

7. Contact is installed between input and output in the converter, But not

allowed to use this contact to control the inverter's start-stop. Necessarily need to control inverter's start-stop by using the contact, not less than one hour intervals. Easy to reduce the use life for capacitors within inverter by reason of charging and discharging continually. If equipped with a contactor and other switching device between the output and the motor, Should ensure that the inverter to carry out On-off operation in the absence of output. Otherwise easily lead to damage to the inverter module.

8. The use without the rated voltage value

Our inverters can not be used exceed permitted work voltage range, easy to cause damage to the device within the inverter. If necessary, please use the appropriate step-up or pressure-relief devices .

9. Three-phase input change to two-phase input

Don't permit of changing three-phase inverter as two-phase to be used, or will result in failure or damage to inverter.

10. Lightning surge protection

The inverter is equipped with over-current protection devices caused by lightning strike, Have a certain capacity for self-protection for lightning, Customers should also install protect at the front-end converter for places where lightning often.

11. Altitude

Inverter can output the rated power when installed with altitude of lower than 1000m. It will be derated when the altitude is higher than 1000m. For details, please contact us.

12. Some special usages

If the customer need to use the wiring diagram that the manual did not mention, such as the common DC bus, please consult us.

13. Inverters scrapped

- 1) The inverter burned inside the electrolytic capacitor may explode.
- 2) Inverters contain the plastic, rubber and other products, that may bring harmful, toxic gases, in the burning, Please particularly careful.
- 3) Please treat the inverter as industrial waste.

14. Adaptive motor

1) Standard adaptive motor for 4 grade Squirrel-cage asynchronous induction motor. If it is not above motor that may select the inverter according to rated current of motor. If you need to drive permanent magnet synchronous motor, please ask for support.

2) The cooling fan of non-inverter motor and the rotor axis is a coaxial connection, the effect of fan cooling is poor when the speed decreases, therefore, should be retrofitted with exhaust fan or replace for the inverter motor in the motor overheat occasion.

3) The inverter has built-in standard parameters of adaptive motor, according to the actual situation, Motor parameter identification needs to be done or personality default value in order to be compatible with the actual value, otherwise it will affect the running results and protection performance.

4) If the short-circuit occurred in the cable or the internal motor will cause the inverter alarm, and even deep-fried machine. When the motor and cable just installed, please first conduct insulation short-circuit tests, routine maintenance is also required to conduct this test regularly.

Notice : To do such testing all must be turn-off between the inverter and tested parts.

**Before using, please read this manual thoroughly to ensure proper usage. Keep this manual at an easily accessible place so that can refer anytime as necessary.**

## 2 Summarize

Please check the following items when unpacking the inverter, the nameplate and ensure it is what you ordered, the entire exterior of the inverter to ensure there are no scratches or other damage caused by the transportation, ensure there is operation manual and warranty card in the packing box, ensure the optional parts are what you need if have ordered any optional parts.

Please contact the local agent if there is any damage in the inverter or optional parts.

Reference "Software Update", different versions of the software functions are different.

### 2.1 Description of Nameplate

MODLE:	A100T5R5G/7R7P	Model
INPUT:	3PH AC380V 50HZ /60HZ	Input Power
OUTPUT:	13A/17A	rated Output Current
S/N:	Bar Code	
SHENZHEN NOWFOREVER ELECTRONICS TECHNOLOGY CO . LTD.		

Chart 2-1 description of nameplate

### 2.2 Production Information

The series is made of 3 model, power range and naming rule as below chart.

Symbol	Model	Power Range
G	Universal Model	0.4~280KW
P	Wind/Water pump Model	0.75~315KW
Z	Injection Machine Model	11~75KW

Chart 2-2 power description of model






Chart 2-3 Naming rule

## 2. 3 Selection Guide

### 2. 3. 1 220V Series Description

Model	Input Power	Rated Output Power (KW)	Rated Output Current (A)	Motor Power (KW)
A100S0R4G	single/3phase AC220V	0.4	3.0	0.4
A100S0R7G	single/3phase AC220V	0.75	5.0	0.75
A100S1R5G	single/3phase AC220V	1.5	8.0	1.5
A100S2R2G	single/3phase AC220V	2.2	10.0	2.2
A100S3R7G	3phase AC220V	3.7	18.0	3.7
A100S5R5G	3phase AC220V	5.5	26.0	5.5
A100S7R5G	3phase AC220V	7.5	34.0	7.5
A100S011G	3phase AC220V	11	50.0	11
A100S015G	3phase AC220V	15	64.0	15
A100S018G	3phase AC220V	18.5	75.0	18.5
A100S022G	3phase AC220V	22	90.0	22

## Summarize

A100S030G	3phase AC220V	30	120.0	30
A100S037G	3phase AC220V	37	150.0	37
A100S045G	3phase AC220V	45	180.0	45
A100S055G	3phase AC220V	55	220.0	55
A100S075G	3phase AC220V	75	300.0	75
A100S090G	3phase AC220V	90	350.0	90
A100S110G	3phase AC220V	110	420.0	110

Chart 2-4 220V series description

**2. 3. 2 380V Series Description**

Input Power:3phase AC380V			Rated Output Power (KW)	Rated Output Current (A)	Motor Power (KW)
Model					
G Series (General)	P Series (Pump)	Z Series (Injection)			
A100T0R4G			0.4	1.6	0.4
A100T0R7G	A100T0R7P		0.75	2.6	0.75
A100T1R5G	A100T1R5P		1.5	3.8	1.5
A100T2R2G	A100T2R2P		2.2	5.1	2.2
A100T3R7G	A100T3R7P		3.7	9	3.7
A100T5R5G	A100T5R5P		5.5	13	5.5
A100T7R5G	A100T7R5P		7.5	17	7.5
A100T011G	A100T011P	A100T011Z	11	25	11
A100T015G	A100T015P	A100T015Z	15	32	15
A100T018G	A100T018P	A100T018Z	18.5	37	18.5
A100T022G	A100T022P	A100T022Z	22	45	22
A100T030G	A100T030P	A100T030Z	30	60	30
A100T037G	A100T037P	A100T037Z	37	75	37

## Summarize

A100T045G	A100T045P	A100T045Z	45	90	45
A100T055G	A100T055P	A100T055Z	55	110	55
A100T075G	A100T075P	A100T075Z	75	150	75
A100T090G	A100T090P		90	176	90
A100T110G	A100T110P		110	210	110
A100T132G	A100T132P		132	250	132
A100T160G	A100T160P		160	300	160
A100T200G	A100T200P		200	380	200
A100T220G	A100T220P		220	420	220
A100T250G	A100T250P		250	480	250
A100T280G	A100T280P		280	540	280
A100T315G	A100T315P		315	600	315
A100T355G	A100T355P		355	700	355
A100T400G	A100T400P		400	780	400
A100T450G	A100T450P		400	780	400
A100T500G	A100T500P		450	880	450
A100T560G	A100T560P		500	980	500
	A100T630P		560	1100	560

Chart 2-5 380V series description

## 2.4 Technology Criterion

Items	Criterion
Frequency range	0~600Hz
Output frequency precision	0.01Hz
Frequency	Digital setting:0.01Hz. Analog setting:AD switch precision for one in thousand.
Speed range	1:100
Overload	G model:150%rated current60s; 180%rated current 2s.

## Summarize

capability	P model:120%rated current 60s; 150%rated current 2s. Z model:150%rated current 60s; 180%rated current 2s.
Control Mode	Open-loop VF control; Open-loop simple vector control.
Torque boost	Manual torque can be adjust; Auto-Torque upgrade the whole frequency band.
Start up Torque	when0.5Hz, rated torque for 150%
Acceleration and deceleration curves	Straight or S curve acceleration and deceleration; four kinds of acceleration and deceleration time; 0.1 ~ 3200.0s continuously adjustable
Jog Function	Jog Frequency: 0.00 ~ 50.00hz; jog acceleration and deceleration: 0.1 ~ 3200.0s continuously adjustable
Standard functions	Start function of REV tracking、 Start DC braking、 Coast to stop DC braking、 Restart after power off instantaneous、 Automatic fault reset、 When accelerating over-current suppression、 over-current reduce the frequency function When constant speed、 over-voltage suppression when slowing down、 Skip frequency function、 simple "one drag two function"、 16th-step running、 simple PLC program running、 Traverse frequency function applies to textile、 closed-loop PID regulator control
Run Rule Channel	Three kinds control mode: keyboard control, analog terminal control, serial communication control
Frequency Source Selection	Digital setting, analog voltage setting, analog current setting, pulse input setting, the serial communication port setting; can be combined through a variety of ways to switch.
Input Terminals	8 digital input terminals, as many as 27 kinds of custom features, is compatible with the active PNP input or NPN input, which one can be used as a high-speed pulse input; Two analog input terminals, one receive only a voltage signal (0 ~ 10V), the other can receive voltage signals (0 ~ 10V) and current signals (0 ~ 20mA);
Output Terminals	Two open-collector output, 16 user defined functions; 1 relay output, up to 27 kinds of user defined functions; 2 analog output, 8 kinds of user defined functions; can export voltage signal (0 ~ 10V) or current signals (0 ~ 20mA)
Protection	Overvoltage, undervoltage and external fault,overcurrent,overheating,overload
Installation place	Indoor, Altitude of less than 1 km, clean, non-corrosive gases and no direct sunlight

Temperature	-10°C ~ +40°C ( Inverter will be derated if ambient temperature exceeds 40° C.)
Humidity	20%~90%RH (without dewfall)
Vibration	Less than 0.5g
Storage Temperature	-25°C~+65°C

Chart 2-6 technology criterion

## 2.5 Functions

1. A100 series inverter with V / f control and vector control technology, with excellent functional module of application .
2. Sensorless vector control (SLVC), built-in test programs of motor parameters, you can easily use the superior performance of vector control.
3. V / F control. Through the whole frequency band of the torque automatic compensation, compensate output torque to meet the requirements of customers for high torque; to improve the dynamic response and motor control features.
4. With a proportional, integral and differential (PID) of the closed-loop control function can be used for constant pressure water supply process control,and so on.
5. With special injection interface board, you can use in injection molding machine energy-saving occasions.
6. Fast current limit (FCL) function, to avoid undue running trip.
7. Built-in DC injection braking.
8. Acceleration / deceleration ramp features have a programmable smoothing function.
9. Automatic voltage regulator, in the case of input voltage changes, the output voltage is basically unchanged, maintaining V / F values constant.
10. Rotate speed tracking ,the inverter will automatically detect the motor

rotate speed, result in the motor is running renewedly and smoothly without the impact to the input enactment frequency .

11. To prevent over-voltage bring on abnormaly speed, the runing inverter automatically limit the increase of DC bus voltage.
12. The monitoring function of runing, the inverter is runing can monitor the output frequency, output current, rotate speed, load rate, accumulated working time, parameters such as DC bus voltage.
13. The fault function of inquiring and monitoring .

## 2.6 DC reactor Options Description

Parts of the A100 series general inverter can be built-in DC reactor, details as below list:

Model	DC reactor		Remarks
	Built-in	External	
A100T0R7G—A100T5R5G	×	×	No special instructions
A100T7R5G—A100T055G	√	×	Inverter model + "L"
A100T075G—A100T200G	×	√	Customers can add by their own
A100T220G—A100T355G	√	√	Inverter model + "L"

"√" yes, "×" not.

Chart 2-7 reactor option description

**Notice:** Because A100T7R5G - A100T055G models can not be an external DC reactor, please give clear indication in speaking for goods if the customer needs.

## 2.7 Braking Resistor Selection Guide

When the inverter-driven control equipment requires rapid braking, need to select the braking unit to release the energy ,when the motor braking feed

back to the DC bus.

The braking resistor of different power levels and different voltage levels inverter selection guide as follows (brake torque 100%).

Model	Braking Resistor Recommended Power	Braking Resistor Recommended Resistance	Braking Unit	Remarks
A100T0R7	150W	$\cong 400 \Omega$	Standard built-in	no special
A100T1R5	250W	$\cong 300 \Omega$		
A100T2R2	300W	$\cong 220 \Omega$		
A100T3R7	400W	$\cong 200 \Omega$		
A100T5R5	500W	$\cong 130 \Omega$		
A100T7R5	800W	$\cong 90 \Omega$		
A100T011	1000W	$\cong 65 \Omega$		
A100T015	1300W	$\cong 43 \Omega$		
A100T018	1500W	$\cong 32 \Omega$	built-in can be selected	Inverter model + "B"
A100T022	2500W	$\cong 25 \Omega$		
A100T030	3500W	$\cong 22 \Omega$		
A100T037	According to the requirements and recommended values of braking unit to select		External braking unit:ABU055	May to use the braking unit of other factory
A100T045				
A100T055				
A100T075				
A100T090				
A100T110				

Chart 2-8 Braking Resistor Selection Guide

## 2. 8 Braking Resistor wiring Description

A100 series inverter braking resistors connected as below.




Chart 2-9 wiring at braking resistor[less than 30kW]




Chart 2-10 wiring at braking resistor [above 37kW]

## 2. 1 The wiring Description at the signal board of injection machine

ONS-ZS-01-930 is our company's option parts of injection molding machine ,it can be used to match with A100 series inverter, which can be directly input 0 ~ 1A (through the CI ~ COM terminal) DC current signal, or 0 ~ 24V (through VI ~ COM terminal) DC voltage signal. after treatment of optical coupling isolation, converted into 0 ~ 10V voltage signal ,through the cable directly connected to the VCI interface of the inverter, users do not need to connect external analog signal line in addition.

**Notice:** When using the injection molding machine signal board, the external analog input VCI、 CCI can not be used.






Chart 2-11 wiring at the signal board of injection machine

#### Injection Molding Machine Connection Description:

You can use the following two kinds of wiring methods, but they can not be used simultaneously.

1. Injection molding machine control panel 0 ~ 24V voltage output to the injection signal plate, VI connect voltage positive terminal, COM connect voltage negative terminal.(relative to injection molding machine control panel)

2. Injection molding machine control panel 0 ~ 1A current output signal to the injection signal plate, CI connect to current inflow terminal (relative to injection molding machine signal board), COM connect to current outflow side (relative to injection molding machine signal board).

## **3 Installation**

### **3.1 Installation Environment**

1. There are vents or ventilation devices in indoor places.
2. Ambient temperature  $-10\text{ }^{\circ}\text{C} \sim 40\text{ }^{\circ}\text{C}$ . If the ambient temperature is bigger than  $40\text{ }^{\circ}\text{C}$ , but lower than  $50\text{ }^{\circ}\text{C}$ , may take off the cover board of inverter or open the front door cabinet, in order to reduce temperature.
3. Try to avoid high temperature and wet places, humidity less than 90%, and without dewfall.
4. Avoid direct sunlight.
5. Away from air pollution such as flammable and corrosive gases, liquids.
6. No dust, floating particles of fiber and metal.
7. It is not allowed that the inverter falls down or suffers from fierce impact or the inverter installed at the place that vibration frequently.
8. Keep away from the electromagnetic radiation source.

### **3.2 Installation Direction and Space**

In order not to affect the life of converter and reduce its performance, it should be noted mounting direction and the surrounding space, and be properly fixed.




Chart 3-1 safe space

### 3.3 Installation dimensions of Inverter




Chart 3-2 External Dimension(0.4~5.5KW)




Chart 3-3 External Dimension (7.5~15KW)




Chart 3-4 External Dimension (18.5~200KW)

## Installation




Chart 3-5 External Dimension (220~560KW)

220V Model	A (mm)	W (mm)	B (mm)	H (mm)	H1 (mm)	D (mm)	Installation Hole (mm)	Net Weight (Kg)
A100S0R4G A100S0R7G A100S1R5G A100S2R2G	112	125	170	180	--	137	φ5.0	--

Chart 3-6 220V External Dimension

380V Model			A (mm)	W (mm)	B (mm)	H (mm)	H1 (mm)	D (mm)	Installation Hole (mm)	Net Weight (Kg)
G Series	P Series	Z Series								
A100T0R7G	A100T1R5P	--	112	125	170	180	--	137	φ5.0	--
A100T1R5GA	A100T2R2P	--								
A100T2R2GA	A100T3R7P	--								
A100T3R7GA	A100T5R5P	--	162	172	233	246	--	174	φ5.5	--
A100T5R5GA	A100T7R5P	--	156	218	327	337	350	178	φ5.5	--
A100T7R5GA	A100T011P	--								

## Installation

380V Model			A	W	B	H	HI	D	Installation Hole	Net Weight
G Series	P Series	Z Series	(mm)	(mm)	(mm)	(mm)	(mm)	(mm)	(mm)	(Kg)
A100T011G	A100T015P	--								
A100T015G	A100T018P	A100T011Z								
A100T018G	A100T022P	A100T015Z								
A100T022G	A100T030P	A100T018Z	220	285	461	459	482	222	φ10	--
A100T030G	A100T037P	A100T022Z								
A100T037G	A100T045P	A100T030Z								
A100T045G	A100T055P	A100T037Z	250	380	625	626	647	295	φ10	--
A100T055G	A100T075P	A100T045Z								
A100T075G	A100T090P	A100T055Z								
A100T090G	A100T110P	A100T075Z	260	466	693	714	740	325	φ10	--
A100T110G	A100T132P	--								
A100T132G	A100T160P	--	270	480	753	775	800	325	φ11	--
A100T160G	A100T200P	--								
A100T200G	A100T220P	--	283	500	1175	1246	1275	397	φ13	--
A100T220G	A100T250P	--								
A100T250G	A100T280P	--								
A100T280G	A100T315P	--	--	750	--	1785	--	400	--	--
A100T315G	A100T355P	--								
A100T355G	A100T400P	--								
A100T400G	A100T450P	--								
A100T450G	A100T500P	--	--	1010	--	1630	--	400	--	--
A100T500G	A100T560P	--								
A100T560G	A100T630P	--								

Chart 3-7 380V External Dimension

## 4 Wiring

### 4.1 Connection of Periperal devices




Chart 4-1 connection of periperal devices

## 4. 2 Typical Wiring Diagram

### 4. 2. 1 Wiring Diagram




Chart 4-2 wiring diagram(A100T3R7G~A100T030G)






Chart 4-3 wiring diagram(A100T037G~A100T055G)




Chart 4-4 wiring diagram(A100T075G~A100T280G)

#### 4.2.1 Terminal configuration




Chart 4-5 Main circuit terminals

<b>Terminal Symbol</b>	<b>Function Description</b>
R, S, T	Terminals of 3 phase AC input
U, V, W	Terminals of 3 phase AC output (connect to motor)
P+	Terminal of positive DC bus
P-	Terminal of negative DC bus
P	Can install DC reactor between P and P+
PB	Can install DC braking resistor between P+ and PB
E	Terminal of ground

Chart 4-6 Description of main circuit symbol

### 4.3 Description of Control Circuit Terminals

A variety of application interfaces can be provided for users by controlling Board, including digital input and output signals, analog input and output signals, keyboard interface, injection molding machine-specific interface.




Chart 4-7 control board layout

### 4. 3. 1 Control Circuit Terminal Layout




Chart 4-8 Control circuit terminals layout

### 4. 3. 2 Description of Control Circuit Terminals

Items		Terminals	Name	Function	Specifications
Input	Digital	X1	Multifunctional Input<X1>	Factory settings:forward run	Optical Coupling Insulation:DC24V/8mA When using an external power, voltage range .9~30V
		X2	Multifunctional Input <X2>	Factory settings:reverse run	
		X3	Multifunctional Input <X3>	Factory settings:Forward jog	

Wiring

Items	Terminals	Name	Function	Specifications	
		X4	Multifunctional Input <X4>	Factory settings:reverse jog	
		X5	Multifunctional Input <X5>	Factory settings:Multistage speed terminals 1	
		X6	Multifunctional Input <X5>	Factory settings: Multistage speed terminals 2	
		X7	Multifunctional Input <X7>	Factory settings: Multistage speed terminals 3	
		X8	Multifunctional Input <X8>	Factory settings: Multistage speed terminals 4(as below notice1)	
		WDC	Multifunctional Input Common	when leaving factory between “ +24 V”to WDC are shorted by the short film	
	Analog	+10V	Analog 10V power	Output capacity:less than 50mA	
		VCI	Analog frequency setting1	DC:0~10V(distinguish:1/1000)	
		CCI	Analog frequency setting2	DC:0~10Vor 0~20mA(distinguish 1/1000)	
		GND	Analog common	0V	
output	Relay	MA	A node output	Factory setting:the stop-machine fault occurred in running MA—MC:NC node MB—MC:NO node	Node Capacity: AC250V, less than 2A; DC30V, less than 1A.
		MB	B node output		
		MC	node output common		
	Digital	Y1	Optical Coupling output 1	Factory setting:the inverter is running	Open-collector output; Optical Coupling Output Capacity:

## Wiring

Items	Terminals	Name	Function	Specifications	
		Y2	Optical Coupling output 2	Factory setting:running frequency reaches the enactment value	DC36V , less than 50mA.
		COM	Optical Coupling output common	0V	
	Analog	AO1	Analog output1	Voltage and current output; factory setting: output frequency	Output Capacity: voltage:0 ~ 10V , less than 2mA; current:0 ~ 20mA,less than 10V
AO2		Analog output 2	Voltage and current output; factory setting: output current		
GND		Analog COM	0V		
Power	+24V	DC24V:power positive	meet“digital input” 、 “digital output”	Output capacity:less than 100mA; When leaving factory “+24V”and“WDC”is shorted	
	COM	DC24V:power negative			
Communication	+485	RS485+	MODBUS	MEMOBUS protocol Max38.4kBPS	
	-485	RS485-			

Notice1:You can set the high-speed pulse input terminals, maximum input 50kHz.

Chart 4-9 control circuit terminals description

### 4. 3. 3 Wiring Description on Control Circuit Terminals

#### 4. 3. 3. 1 Analog Input Terminals

Analog input is easy interfered by environment on account of voltage signal had used,please use shielded cables, and to ensure a reliable shield grounding. Wiring distances as short as possible and away from power lines. When occuring Serious interfere in a occasion, can plus filter capacitor or iron oxide core in the signal lines.




Chart 4-10 wiring diagram of analog input

#### 4. 3. 3. 2 Digital Input Terminals

Digital input is divided into NPN transistor input and PNP transistor input.

NPN transistor input, use internal 24V power, +24 V terminal and the WDC terminals are shorted.




Chart 4-11 wiring diagram of NPN transistor input

When using PNP transistor input, use an external 24V power supply, its negative terminal connect WDC; external power positive terminal for the public point. external power voltage range: 9 ~ 30V.




Chart 4-12 PNP wiring diagram of NPN transistor input  
(external power positive terminal for common point)

#### 4. 3. 3. 3 Digital Output Terminals

Digital output for the open-collector output, if you use an external power supply, please connect the external power negative terminal to COM terminal. The maximum current of open-collector output is 50mA, if the relay is external load, please install freewheeling diode at both ends of relay.

Notice: Please properly install freewheeling diode polarity, otherwise it will damage the internal components.




Chart 4-13 wiring diagram of digital output

#### 4. 3. 4 Jumpers and interface on control board

Name	Function
AO1 jumper	choice AO1 output analog : voltage0~10V; current 0~20mA



## Wiring

Name	Function
AO2 jumper	choice AO2 output analog : voltage 0~10V; current 0~20mA
CCI jumper	choice CCI input analog : voltage 0~10V; current 0~20mA
CN3 interface	Keyboard interface
CN4 interface	Interface For External Injection Molding Machine

Chart 4-14 Jumpers on control board

## 5 Operation

### 5.1 Keypad Description

#### 5.1.1 Keypad schematic diagram




Chart 5-1 Keypad schematic diagram

#### 5.1.2 Key function description

Button symbol	Name	Function
MONITOR/ESC	Monitor/Escape key	1. Switch to system monitor state. 2. Escape to previous menu. 3. In alarm state, clear away alarm.
DATA/ENTER	Data/Enter key	1. Enter menu 2. Confirm modified data.

Button symbol	Name	Function
>>	Shift key	<ol style="list-style-type: none"> <li>In fast monitor state, switch the monitor parameters.</li> <li>When you want to modify the data, switch to the bit you want to modify</li> <li>When modifying function code, per10 to increase. (valid only P0 function group).</li> </ol>
▲	UP key	Increase data or function codes
DIR/ JOG	Jog key	According to this function code can achieve a function: <ol style="list-style-type: none"> <li>Switch between forward and reverse.</li> <li>Start-up the inverter in JOG state, relax the key result in stopping JOG</li> </ol>
RUN	Run key	Start to run the inverter in keypad control mode.
▼	DOWN key	Decrease function codes or data.
STOP/ RESET	Stop / Reset key	<ol style="list-style-type: none"> <li>In running status, stop the inverter.</li> <li>When fault alarm, can be used to reset the inverter without any restriction.</li> <li>Emergency stop function can be realized. (Equivalent to the external fault input)</li> </ol>

Chart 5-2 Key function description

### 5. 1. 3 Indicator light description

#### 5. 1. 3. 1 Run state indication

Indicator Light Name	Indicator Light State	State Description
RUN	Light on	Operating or JOG status
	Flickering	The inverter is decreasing speed until stop.
	Extinguished	stop status
DIR	Light on	Reverse state
	Flickering	Switching to forward and reverse.
	Extinguished	Forward state
LOCAL	Light on	Operation panel control state (local control)
	Extinguished	Terminals or communication control state
TRIP	Light on	Not serious fault alarm (over current, over voltage)
	Extinguished	The inverter output current and generatrix voltage are normal

Chart 5-3 run state indicator light description

### 5.1.3.2 Unit indication

In fast monitor state, indicate monitor unit and data.

Data order	Indication	Range	Unit
Setting frequency	Hz light on	0.00~600.00Hz	0.01Hz
Output frequency	Hz flickering	0.00~600.00Hz	0.01Hz
Output current	A light on	0.1~2000.0A	0.1A
Output voltage	V light on	0.1~2000.0V	0.1V
DC bus voltage	V flickering	100~1000V	1V
Run rotate speed	Hz、A light on	0~30000rpm	1rpm
Load rate	A、V light on	0.0~200.0% (motor rated load)	0.1%
Output power	A、V flickering	0.00~200.00% (motor rated power)	0.01%
Output torque	A flickering	0.00~200.00% (motor rated torque)	0.01%
Over loading counter	Hz、V light on	0.0~100.0%	0.1%
Inverter temperature	Hz、V flickering	0~100℃	1℃
PID closed loop setting	Hz、A、V light on	0.00~10.00V	0.01V
PID closed loop feedback	Hz、A、V flickering	0.00~10.00V	0.01V

Chart 5-4 unit indicator light description

### 5.1.4 Digital display

Have 6 digit LED , which can display data values.

## 5.2 Operation process

Four levels of menu as below:

Operation state	Main contents
Fast monitor	Fast monitor 13 kinds of run states such as setting frequency, output frequency and so on.
Function code setting	Modify function code, the P function group of first-level menu.
Information query	Inquire about information and run state .the d function group of first-level menu.
Fault Alarm Reset	The inverter fault alarm display and reset.

Quick modify keyboard digital setting	When the frequency setting source is the keyboard digital setting, modify the setting frequency rapidly. (UP, DOWN function)
---------------------------------------	--

Chart 5-5 Description of the inverter operation status

### 5. 2. 1 Fast-monitoring

After power-on initialization, the inverter automatically switches to the fast monitor status. If enter the fast-monitoring status in other states, you can press "monitor key" to enter. In the fast-monitoring state, use the "shift key" to switch monitor parameters. A total of 13 operational status can be monitored, the monitor status order and the dicator light reference Chart 5-4.




Chart 5-6 fast-monitoring diagram

### 5. 2. 2 Function codes setting

The function codes of P0、P1、P2 function group in first-level menu are can read-write parameters, users can modify.




Chart 5-7 Function code setting diagram

### 5. 2. 3 Information Query

The function codes of d0、d1、d2、d3 function group in first-level menu for read only parameters, users can only look over.




Chart 5-8 Information query diagram

### 5. 2. 4 Fault Alarm Reset

If the inverter has fault or alarm, it will prompt the related fault information. Codes for the E001 to E030.

If the inverter has E001 to E029 fault, please use the "reset button" to clear the fault.

If the inverter has a E030 alarm, please use the "ESC button" to clear the alarm.

### 5. 2. 5 Keyboard digital setting modify rapid

When P0-002 = 0, P0-003 = 1, the frequency source for the keypad digital setting.

Inverter in a parking state, UP, DOWN monitor a given frequency in effect in the fast-monitoring mode;

Inverter in running, UP, DOWN in effect in the fast-monitoring mode;

You can set P0-008, to prohibit UP, DOWN adjustment function

## 5. 3 Motor parameter autotuning

If select the vector control run mode, in order to ensure control

performance, need to check motor parameters. Motor parameters self-learning the steps are as follows:

First, set the key P0-001 = 0, using the disc control mode.

And then set the detection mode P0-026.

P0-026 = 1 for spin detection, detect the no-load current and stator resistance, the motor can running during the operation, Accelerate time and decelerate time can be set by the P0-012, P0-013 when the rotation detect, but when P0 -012, P0-013 value is less than 15.0s, it will use the accelerate and decelerate time of 15.0s. Please set the accelerate and decelerate timeis more than 60s for 50kW motor;

P0-026 = 2 for static testing, only the stator resistance is test, the motor can not running during the operation.

Set Motor nameplate parameters.

P0-016: Motor rated power; P0-017: Motor rated frequency; P0-018: Motor rated voltage; P0-019: Motor rated current; P0-020: Motor rated speed.

And then press the "Run button" of the operation keyboard, the inverter will automatically detect motor parameters, and then stop running.

If the detection had been completed successfully,P0-026 will automatically be changed to 0, inverter return to static state.

.If the automatic detection fails, the inverter will stop testing; when re-run, it will resume testing. If after a fault, do not want to re-start the detection, please modify P0-026 to 0.

## 5.4 Quick debugging

Set the basic function code in operation ,refer to the following diagram .




Chart 5-9 Quick debugging flowchart



## 6 Detailed Function description

This chapter introduces the function code setting of the P0, P1, P2 function group. d0, d1, d2, d3 function group for running information demand of the inverter, reference "9 Function Code List" .

### 6.1 P0 Group--Basic Function

#### 6.1.1 Basic Function

P0-000	Control mode for speed	setting range:0~1	factory setting:0
--------	------------------------	-------------------	-------------------

0:VVVF Control.

1:vector control. Before using this control mode, please had completed motor parameter autotuning.

Notice: Function Group 6.1.3 V / F curve parameters in vector control is also effective.

P0-001	Select command source	Setting range:0~2	factory setting:0
--------	-----------------------	-------------------	-------------------

Command source is that a channel ,the inverter receives some instructions (run、stop、jog、running direction).

0: keyboard control.

1:Analog terminal control

2:communication control

Notice: You can use"command source switch" Terminal, switch to local control (keyboard control).

Control terminal of command source state	P0-001 setting	the command source of actual use
Invalid	0	0
Invalid	1	1
Invalid	2	2

## Detailed Function description

Control terminal of command source state	P0-001 setting	the command source of actual use
Effective	0	0
Effective	1	0
Effective	2	0

Chart 6-1 switch description of command source

Setting frequency is controlled by the commands of running and JOG, both are valid, it will be in the running. Reference the logic diagram as shown below.




Chart 6-2 PRI description of running and JOG

P0-002	Select frequency source	Setting range:0~4	Factory value:0
--------	-------------------------	-------------------	-----------------

0:Main frequency source x.

1:Assisiant frequency source Y.

2:Main frequency source X+ Assistant frequency source Y.

3:MAX (Main frequency source X, Assisiant frequency source Y) .

4:Ensured by selection terminals of frequency source.

Selection terminals of frequency source1	Selection terminals of frequency source2	Frequency source in using
Invalid	Invalid	0
Invalid	Effective	1
Effective	Invalid	2
Effective	Effective	3

Chart 6-3 selection terminals description of frequency source

P0-003	Main frequency source x selection	Setting range:0~10	Factory value:0
P0-004	Assistant frequency source Yselection	Setting range:0~10	Factory value:0

0: Keyboard potentiometers. Adjustable range between the lower frequency and maximum frequency.

1: Keyboard digital settings (UP, DOWN). When inverter in a parking state, it is effective to monitor setting frequency in the fast-monitoring mode with UP, DOWN key ; When inverter in running, it is effective in the fast-monitoring mode with UP, DOWN key.

2:VCI. Setting frequency is controlled by the input analog terminal VCI . reference P0-057 instructions.

3:CCI.Setting frequency is controlled by the input analog terminalCCI. reference P0-062 instructions.

4:Simple PLC running. Setting frequency is controlled by interior PLC program. reference P0-149 instructions.

5:Multi-segment speed. Setting frequency is controlled by the multi-function input terminals . reference P0-132 instructions.

6:PID closed loop running. Setting frequency is set by PID operation.reference P0-170 instructions.

7: PULSE input setting. Setting frequency is controlled by the input pulse . reference P0-067 instructions.

8:serial communication settings. Setting frequency is set by the serial communication, reference the description of serial communication.

9:VCI mode 2. When the multi-segment speed terminal is invalid, the setting frequency is controlled by the analog input terminal VCI . When the multi-segment speed terminal is effective, select multi-segment speed 1 to 15. Reference P0-132 instructions.

10:CCI Mode 2. When the multi-segment speed terminal is invalid, the setting frequency is controlled by the analog input terminal CCI . When the multi-segment speed terminal is effective,select multi-segment speed 1 to speed 15.

Reference P0-132 instructions.

P0-005	Main frequency source x gain	Setting range:0.10~10.00	Factory value:1.00
P0-006	Assistant frequency source Y gain	Setting range:0.10~10.00	Factory value:1.00

Set the frequency gain of frequency source. Significance of 0.10 is 0.1 times; 10.00 means that magnify 10 times.

P0-007	Keyboard digital setting frequency	Setting range: 0.00~600.00Hz	Factory value:50.00Hz
--------	------------------------------------	---------------------------------	-----------------------

Set the keyboard digital setting frequency value .

P0-008	Keyboard and terminals UP/DOWN setting	Setting range:0~2	Factory value:1
--------	--	-------------------	-----------------

0:invalid.

1:effective, no saving after power off. After having changed the set frequency P0-007 by UP / DOWN, when the inverter power off, P0-007 is not stored in the EPP.

2:effective, saving after power off. After having changed the set frequency P0-007 by UP / DOWN, when the inverter power off, P0-007 is stored in the EPP.

P0-009	Running direction control	Setting range:0~2	Factory value:0
--------	---------------------------	-------------------	-----------------

0: It is same with setting direction. Run according to the instruction direction .

1: It is opposite with the setting direction. Run according to the instruction

opposite direction . the function can change the direction of motor rotation ,but don't change the wiring between the inverter and the motor .

2: reverse prohibited. reverse run is prohibited.

In run or Jog mode, the control of running direction please refer to the logic diagram shown below.




Chart 6-4 PRI description of running directions control

P0-10	Upper limit frequency	Setting range:0.00~600.00Hz	Factory value:50.00Hz
P0-11	Lower limit frequency	Setting range:0.00~600.00Hz	Factory value:0.00Hz

Set the maximum and minimum value of output frequency.

Notice :set the upper and lower limit frequency mostly prevent personnels mistake operation.inverter will avoid the motor overheat caused by low frequency , or because of the high frequency caused by mechanical wear and so on.

P0-12	Accelerate speed time0	Setting range:0.1~3200.0s	Factory value:15.0s
P0-13	Decelerate speed time0	Setting range:0.1~3200.0s	Factory value:15.0s

Acc/Dec time of the “0” group , default Acc/Dec time in using. Can use Acc/Dec time of the other three groups by Multi-function terminal selection.

This function code of 15.0s the meaning for the accelerate time(0 Hz ~50 Hz) or deceleration time(50 Hz~0 Hz).

Notice: The factory value is different according to inverter power.

P0-14	Carrier frequency	Setting range:1.0~10.0KHz	Factory value:Model
-------	-------------------	---------------------------	---------------------

## Detailed Function description

			option
--	--	--	--------

Set the PWM output carrier frequency. Carrier frequency have effect for the motor noise、inverter thermal and environment interference、temperature rise of motor and inverter.

When carrier setting value higher than the default factory value, the inverter heat increased, please select bigger capacity inverter

Carrier frequency	Electromagnetism noise	Cacophony/leak current	Inverter temperature rise	Motor temperature rise	Motor noise	outputcurrentwave
2KHZ	small	small	small	big	big	poor
5KHZ						
10KHZ	big	big	big	small	small	Good

Chart 6-5 Setting reference of carrier frequency

P0-015	Adjust selection of carrier frequency	Setting range:0~3	Factory value:Model option
--------	---------------------------------------	-------------------	----------------------------

0: Fixed PWM, the carrier temperature adjustment is invalid.

1: fixed PWM, the carrier temperature adjustment is effective.

2: random PWM, the carrier temperature adjustment is invalid.

3: random PWM, the carrier temperature adjustment is effective.

G model default value for 0, P model default value for 2.

### 6. 1. 2 Motor Parameters

P0-016	Rated power of motor	Setting range:0.4 ~ 1000.0KW	Factory value:Model option
P0-017	Rated frequency of motor	Setting range:1.00 ~ 600.00Hz	Factory value:50.00Hz
P0-018	Rated voltage of motor	Setting range:10.0~440.0V	Factory value:Model option
P0-019	Rated current of motor	Setting range:1.0~2000.0A	Factory value:Model option
P0-020	Rated rotate speed of motor	Setting range:5~30000rpm	Factory value:1460rmp

Please set it according to motor nameplate .

## Detailed Function description

P0-021	No-load current of motor	Setting range:10.0~100.0%	Factory value:40.0%
--------	--------------------------	---------------------------	---------------------

This parameter affect the performance of vector control, please use the motor parameter autotuning.

P0-022	Stator resistance	Setting range:0.001~65.000Ω	Factory value:Model option
--------	-------------------	-----------------------------	----------------------------

This parameter affect the performance of vector control, please use the motor parameter autotuning.

In “VVVF”control, VVVF control, this parameter will also affect automatic torque compensation and automatic slip compensation.

P0-026	motor parameter autotuning	Setting range:0~2	Factory value:0
--------	----------------------------	-------------------	-----------------

0:invalid. After successful tests will also be automatically set to 0.

1: Rotation Test. Motor run under no-load condition, to check the two parameters of motor no-load current and stator resistance.

2: static test. If the motor and the load connected, when the motor does not run under no-load , check the parameter of stator resistance.

Details please refer to 5.3 Motor parameters autotuning.

### 6. 1. 3 V/F Curve Parameter

The function group is valid in the VVVF and vector control.

P0-027	V/F curve setting	Setting range:0~7	Factory value:0
--------	-------------------	-------------------	-----------------

0:linearity;      1: 1.3order;      2: 1.7order;      3: 2.0order;

4: High-torque curve 1;    5: High-torque curve 2;    6: High-torque curve 3;

7: four-point curve




Chart 6-6 V/F curve chart

P0-028	V/F voltage point 0	Setting range:0.0~15.0%	Factory value:1.0%
--------	---------------------	-------------------------	--------------------

Set 0Hz corresponding output voltage. 1.0% significance of the function code for motor rated voltage (P0-018). For the heavy load can be a gradual increase rate of 1.0% of the value.

P0-029	V/F frequency point1	Setting range:0.0~100.0%	Factory value:40.0%
P0-030	V/F voltage point1	Setting range:0.0~100.0%	Factory value:40.0%
P0-031	V/F frequency point2	Setting range:0.0~100.0%	Factory value:80.0%
P0-032	V/F voltage point2	Setting range:0.0~100.0%	Factory value:80.0%

Set the frequency and voltage of two mid-point in a four-point V / F curve . This function code “ 1.0%”, respectively correspond with 1.0% motor rated frequency (P0-017) or 1.0% motor rated voltage (P0-018).



#### 6. 1. 4 VVVF Control Parameter

The function group is only effective under the VVVF control.

P0-033	Automatic torque compensation gain	Setting range:0.0~250.0%	Factory value:100.0%
--------	------------------------------------	--------------------------	----------------------

Inverter will automatically adjust the output voltage to maintain motor torque constant, especially low-frequency running to make up the voltage drop of stator resistance. When the torque is not enough to increase the function code, when the motor current is too large to decrease the function code.

This function code for 0.0 mean that the automatic torque compensation is prohibited.

P0-034	Automatic torque compensation filter	Setting range:0.01~5.00s	Factory value:0.10s
--------	--------------------------------------	--------------------------	---------------------

This function code is used to set the response speed of automatic torque compensation. When the motor jitter and fluctuation of rotate speed are large, please increase the function code.

P0-035	Automatic slip compensation gain	Setting range:0.0~250.0%	Factory value:0.0%
--------	----------------------------------	--------------------------	--------------------

This function is used to improve the motor speed by reason of load changes. When Load is stable, if the motor fluctuation of rotate speed is large, please reduce the function code.

This function code for 0.0 mean that the automatic slip compensation is prohibited.

P0-036	Auto slip compensation filter	Setting range:0.01~5.00s	Factory value:0.10s
--------	-------------------------------	--------------------------	---------------------

The function code is used to set response speed of automatic slip compensation. When the motor jitter and fluctuation of rotate speed are large, please increase the function code.

P0-037	AVR ( Auto Voltage Regulation)	Setting range:0~2	Factory value:2
--------	--------------------------------	-------------------	-----------------

0:Invalid.

1: Effective at all time. When the input voltage is not stable, automatically adjust output voltage to prevent output voltage is influenced by the fluctuation of input voltage.

2: Invalid only as deceleration to stop mode.Because the braking torque will be reduced owing to use AVR function in speed-down, so that you can choose to close the function in speedup .

P0-038	energy-saving run	Setting range:0~1	Factory value:0
--------	-------------------	-------------------	-----------------

0:Invalid

1:Effective.Output power of the inverter will automatically reduce the output voltage to achieve energy-saving purposes. For the heavy load, the function will be prohibited.

P0-039	voltage limit of energy-saving running	Setting range:20.0~100.0%	Factory value:80.0%
--------	--	---------------------------	---------------------

Set the minimum voltage of energy-saving running. When the function code for100.0%, it said that standard voltage of output in accordance with VF curve.

### 6. 1. 5 Vector control parameter

The function group is only effective under the vector control.

P0-040	ASR gain	Setting range:50.0~200.0%	Factory value:100.0%
P0-041	ASR filter	Setting range:0.01~1.00s	Factory value:0.10s

Speed loop PI regulation. When the velocity fluctuation, an increase in the speed loop filter.

## Detailed Function description

P0-042	Current-loop gain	Setting range:50.0~200.0%	Factory value:100.0%
P0-043	Current-loop filter	Setting range:0.01~1.00s	Factory value:0.10s

Current loop PI regulator. When the velocity fluctuation, an increase in current loop filtering.

P0-044	Vc torque compensation gain	Setting range:50.0~250.0%	Factory value:100.0%
--------	-----------------------------	---------------------------	----------------------

To set torque compensation value during vector control

P0-045	VC Slip compensation gain	Setting range:50.0~250.0%	Factory value:100.0%
--------	---------------------------	---------------------------	----------------------

To set slip compensation value during vector control

### 6. 1. 6 Input terminals

P0-046	X1 terminal function	Setting range:0~30	Factory value:1
P0-047	X2 terminal function	Setting range:0~30	Factory value:2
P0-048	X3 terminal function	Setting range:0~30	Factory value:7
P0-049	X4 terminal function	Setting range:0~30	Factory value:8
P0-050	X5 terminal function	Setting range:0~30	Factory value:23
P0-051	X6 terminal function	Setting range:0~30	Factory value:24
P0-052	X7 terminal function	Setting range:0~30	Factory value:25
P0-053	X8 terminal function	Setting range:0~30	Factory value:26

Notice: When the X terminal as an "internal counter clock input", set the P0-054 for 1.

0: invalid. Idle input terminals.

1: Forward run. Forward run command input.

2: Reverse run. Reverse run command input.

3: 3-wire control. 3-wire system to run auxiliary input commands.

4: Fault reset. Fault reset command input, equal to the "reset button."

5: UP command. Increasing frequency command input.

6: DOWN command. Reduce the frequency command input.

- 7: Forward jog. Forward jog command input.
- 8: Reverse jog. Reverse Jog command input.
- 9: Coast to stop. Receives the instruction, the inverter stop output immediately, motor coast to stop.
- 10: external fault input. Used as external mechanical fault signal of inverter.
- 11: Acc/Dec speed Pause. Acc/Dec speed pause, the output frequency remain unchanged.
- 12: PLC run reset. PLC from the first segment 0 starts running again.
- 13: PLC pause. PLC internal timer stop time.
- 14: Traverse run reset. After output frequency reaches set frequency, it will start again traverse run.
- 15: Traverse pause. output frequency will remain unchanged.
- 16: PID operation pause. Set frequency of PID operation will remain unchanged.
- 17: Clear PID integral time.
- 18: switch command source. This command is used to switch to local control (keyboard control). See P0-001 Function Code Description.
- 19: Frequency Source Select 1. See P0-002 Function Code Description.
- 20: Frequency source selection 2.
- 21: Acc/dec speed selection 1. See P0-094 Function Code Description.
- 22: Acc/dec speed selection 2.
- 23: Muti-step speed terminal 1. See P0-132 Function Code Description.
- 24: Muti-step speed terminal 2.
- 25: Muti-step speed terminal 3.
- 26: Muti-step speed terminal 4.
- 27: Internal counter clock input. Counter clock input. When using this function, please set P0-054 for 1.
- 28: Reset internal counter. Counters will be cleared.

29: Enabled internal timer . When the signal is effective, the timer began to time.

30: Reset internal timer. Timer will be cleared.

P0-054	X input filter times	Setting range:1~50	Factory value:20
--------	----------------------	--------------------	------------------


Set 8 X terminal filter, the bigger value match the bigger the filtering. when the X terminal has error action , please increase the value.

P0-055	Control mode of terminal	Setting range:0~3	Factory value:0
--------	--------------------------	-------------------	-----------------

0: 2-wire model1;      1: 2-wire mode 2.

2: 3-wire mode 1;      3: 3-wire mode 2.

2-wire run mode only need to connect two signals: Forward run and reverse run.



2-wire mode 1


K1	K2	Run command
OFF	OFF	stop
ON	OFF	Forward
OFF	ON	Reverse
ON	ON	stop

2-wire mode 2

K1	K2	Run command
OFF	OFF	Stop
ON	OFF	Forwaed
OFF	ON	Stop
ON	ON	Reverse


Chart 6-7 Diagram of two-wire run mode

3-wire run mode need to connect three signals: Forward run, reverse run, 3-wire run assistant.



SB1: Run  
 SB2: stop  
 SB3: Switching for direction

3 wire mode 1



SB1: run  
 SB2: stop  
 K1: Running direction(OFF:forward; ON:reverse)

3 wire mode 2

Chart 6-8 3-wire run mode diagram

P0-056	UP/DOWN range	Setting range:0.01~100.00Hz/s	Factory value:10.00Hz/s
--------	---------------	-------------------------------	-------------------------

Adjust the setting frequency range to use a keyboard or terminal

P0-057	VCI min input	Setting range:0.00 ~ 10.00V	Factory value:0.00V
P0-058	VCI min input corresponding frequency	Setting range:0.00 ~ 600.00Hz	Factory value:0.00Hz
P0-059	VCI max input	Setting range:0.00 ~ 10.00V	Factory value:10.00V
P0-060	VCI max input corresponding frequency	Setting range:0.00 ~ 600.00Hz	Factory value:50.00Hz

Input curve diagram, such as chart 6-9




Chart 6-9 Analog or pulse corresponding frequency setting curve

P0-061	VCI input filter time	Setting range:0.01~5.00s	Factory value:0.10s
--------	-----------------------	--------------------------	---------------------

Set VCI analog input filter time, when the analog fluctuation is severe, please increase the value .

P0-062	CCI min input	Setting range:0.00~10.00V	Factory value:0.00V
P0-063	CCI min input corresponding frequency	Setting range:0.00~600.00Hz	Factory value:0.00Hz
P0-064	CCI max input	Setting range:0.00~10.00V	Factory value:10.00V
P0-065	CCI max input corresponding frequency	Setting range:0.00~600.00Hz	Factory value:50.00Hz

Input curve diagram, such as Chart 6-9 chart 6-9.

P0-066	CCI input filter time	Setting range:0.01~5.00s	Factory value:0.10s
--------	-----------------------	--------------------------	---------------------

Set CCI analog input filter time, when the analog fluctuation is severe, please increase the value.

P0-067	PULSE min input	Setting range:0.00~50.00KHz	Factory value:0.00KHz
P0-068	PULSE min input corresponding frequency	Setting range:0.00~600.00Hz	Factory value:0.00Hz

## Detailed Function description

P0-069	PULSE max input	Setting range:0.00~50.00KHz	Factory value:50.00KHz
P0-070	PULSE max input corresponding frequency	Setting range:0.00~600.00Hz	Factory value:50.00Hz

PULSE can only input through X8 terminal. X8 as a high-speed pulse input, please set P0-053 to 0.

Input curve diagram, such as the chart 6-9.

P0-071	PULSE input filter time	Setting range:0.01~5.00s	Factory value:0.10s
--------	-------------------------	--------------------------	---------------------

Set the pulse input filter time, when the pulse fluctuation is severe, please increase the value .

### 6. 1. 7 Output terminals

P0-072	Relay output selection	Setting range:0~19	Factory value:1
P0-073	Y1 output selection	Setting range:0~19	Factory value:2
P0-074	Y2 output selection	Setting range:0~19	Factory value:3

0: No output. Output terminal is idle.

1: Stop fault occurred in running. the effective signal will be output when stop fault.

2: inverter running. the effective signal will be output when running.

3: Run frequency reaches the setting value. See P0-110 Function Code Description.

4: Upper limit frequency running. When run frequency reaches Upper limit, output is an effective signal.

5: Lower limit frequency running. When run frequency reaches lower frequency, output is an effective signal.

6: Inverter zero speed running. When run frequency reaches 0Hz, output is an effective signal.

7: The run frequency level detection. See P0-111 Function Code Description.

8: overload pre-alarm. When the output current is bigger than or equal



overload warning value, output is an effective signal.

9: A minor fault occurred in running. A minor over-voltage or over-current fault occurred in running, output is an effective signal.

10: Inverter run is ready. Inverter without fault, waiting for run commands, output is an effective signal.

11: External fault stopped. When have a external fault signal, output is an effective signal.

12: inverter under voltage stopped in running. undervoltage fault occurs in running, output is an effective signal.

13: Inverter forward running. Forward running, output is an effective signal.

14: Inverter reverse running. Reversal running, output is an effective signal.

15: auxiliary motor. As simple " a drag two functions." See P0-113 ~ P0-114 Function Code Description.

16: The internal counter reaches the specified value. See P0-188 ~ P0-190 Function Code Description.

17: The internal counter reach the final value. See P0-188 ~ P0-190 Function Code Description.

18: Internal timer cycles to be reached. See P0-191 ~ P0-192 Function Code Description.

19: under-voltage pre-alarm. See P0-194 Function Code Description.

P0-075	AO1 output selection	Setting range:0~7	Factory value:0
P0-076	AO2 output selection	Setting range:0~7	Factory value:1

Set the physical meaning of analog output. The maximum output range is 10V.

0: Output frequency. Output frequency is 50.00Hz corresponds to 10V output.

1: output current. Output current for rated current of motor corresponds to 10V output.

2: output voltage. The output voltage is 500.0V corresponds to 10V output.

3: Setting frequency. Setting frequency is 50.00Hz corresponds to 10V output.

4: DC bus voltage. DC bus voltage is 500V corresponds to 10V output.

5: VCI input voltage. VCI input voltage is 10V corresponding to 10.00V

Output

6: CCI input voltage. CCI input voltage is 10.00V corresponds to 10V output.

(when CCI for the current input, 20mA corresponds to 10V)

7: PULSE input. PULSE Input is 10V correspond to 50.00kHz output.

P0-077	AO1 output gain	Setting range:0.10~10.00	Factory value:1.00
P0-078	AO2 output gain	Setting range:0.10~10.00	Factory value:1.00

Set analog output gain.

The following diagram for the analog function of AO1 as "output frequency" , show the output gain setting.




Chart 6-10 Analog Output Gain diagram

### 6. 1. 8 Start and Stop Control

P0-079	Start mode	Setting range:0~2	Factory value:0
--------	------------	-------------------	-----------------

0: Start the inverter at the starting frequency. Start the inverter according to a certain starting frequency .

1: First DC-braking before starting. Inverter will output DC current firstly and then start the motor at the starting frequency. It is suitable for the motor which

have small inertia load.

2: Speed Tracking start. It is suitable for the motor which have small inertia load. Inverter output voltage is automatically adjusted according to the output current, in order to reduce over-current faults at starting..

P0-080	Starting frequency	Setting range:0.00~10.00Hz	Factory value:0.00Hz
P0-081	Hold time of starting frequency	Setting range:0.00~60.00s	Factory value:0.00s

Set starting frequency at starting and hold time of start frequency.

P0-082	Start DC braking current	Setting range:0.0~150.0%	Factory value:0.0%
P0-083	Start DC braking time	Setting range:0.0~60.00s	Factory value:0.00s

Set DC braking current at starting and braking time.

P0-084	Start mode of REV tracking	Setting range:0~1	Factory value:0
--------	----------------------------	-------------------	-----------------

0: Start to track starting at setting frequency . It is suitable for to majority running environment, but when the motor speed of the free glide is higher than the motor speed of setting frequency, over-voltage fault will easy occur.

Please set the setting frequency higher the motor speed of the free glide in order to prevent overvoltage faults.

1: Track start from Upper limit began. When the motor speed of the free glide close to Upper limit, please use this mode.

P0-085	Stop mode	setting range:0~1	Factory value:0
--------	-----------	-------------------	-----------------

0: Deceleration to stop. When the stop command takes effect, the inverter decreases the output frequency according to the selected Acc/Dec time till stop.

1: Coast to stop. When the stop command takes effect, the inverter stops the

output immediately. The motor coasts to stop by its mechanical inertia.

P0-086	Starting frequency of DC braking	Setting range:0.00~50.00Hz	Factory value:0.00Hz
P0-087	Waiting time before DC braking	Setting range:0.01~60.00s	Factory value:0.01s
P0-088	DC braking current	Setting range:0.0~150.0%	Factory value:0.0%
P0-089	DC braking time	Setting range:0.0~60.00s	Factory value:0.00s

The inverter decelerate to stop, inverter stop output period of time(Waiting time before DC braking) when output frequency decelerates to starting frequency of DC braking, then DC braking will be start. DC braking current and DC braking time can be set separately .

When P0-086 = 0, that stop DC braking is invalid.

P0-090	Dead of time FWD/REV	Setting range:0.01~60.00s	Factory value:0.50s
--------	----------------------	---------------------------	---------------------

Set the hold time at zero frequency in the transition between forward and reverse running.




Chart 6-11 FWD/REV dead time diagram

P0-091	Restart after power off instantaneous	Setting range:0~1	Factory value:0
--------	---------------------------------------	-------------------	-----------------

0: invalid.

1: effective. When running the bus voltage is too low result in under-voltage fault occurs, the inverter will automatically reset the fault, and then run

automatically.

P0-092	waiting time for restart	Setting range:0.01~60.00s	Factory value:0.10s
--------	--------------------------	---------------------------	---------------------

Set waiting time for restart , the inverter wait for setting value of the function code after under -voltage occurs, then reset the fault automatically to run.

P0-093	least output frequency setting	Setting range:0~1	Factory value:0
--------	--------------------------------	-------------------	-----------------

When setting frequency less than lower limit frequency, set the inverter output frequency.

0: limit frequency to run less than 0.

1: Sleep Stand-by (0Hz output).

### 6. 1. 9 Acc/Dec assistant

P0-094	Acc/Dec mode selection	Setting range:0~1	Factory value:0
--------	------------------------	-------------------	-----------------

0: Linear acceleration and deceleration. According to setting acceleration and deceleration time to change output frequency. 4 group acceleration and deceleration time can be selected, you can choose acceleration and deceleration time via multi-function input terminals. See the chart 6-12.

1: S curve acceleration and deceleration. Smooth acceleration and deceleration of the initial segment and end segment, reducing the impact to machinery and equipment.

Acc/Dec selection1	Acc/Dec selection 2	Acc/Dec time selected
OFF	OFF	Acc time0、 Dec time0
OFF	ON	Acc time1、 Dec time1
ON	OFF	Acc time2、 Dec time2
ON	ON	Acc time3、 Dec time3

Chart 6-12 Acc/Dec time of terminals selection

P0-095	S curve acceleration characteristic time	Setting range:0.2~2.0s	Factory value:0.5s
P0-096	S curve deceleration characteristic time	Setting range:0.2~2.0s	Factory value:0.5s

S curve characteristic time means that the acceleration and deceleration time from 0 to the time of setting deceleration time. Acceleration and deceleration set separately.

P0-097	ACC time 1	Setting range:0.1~3200.0s	Factory value:15.0s
P0-098	DEC time 1	Setting range:0.1~3200.0s	Factory value:15.0s
P0-099	ACC time 2	Setting range:0.1~3200.0s	Factory value:15.0s
P0-100	DEC time 2	Setting range:0.1~3200.0s	Factory value:15.0s
P0-101	ACC time 3	Setting range:0.1~3200.0s	Factory value:15.0s
P0-102	DEC time 3	Setting range:0.1~3200.0s	Factory value:15.0s

Group 1, Group 2, Group 3 Acc/Dec time, can be selected by multi-function terminals. can also be selected at PLC run time.

Notice: Factory value will be different according to different inverter power.

### 6. 1. 10 Auxiliary function

P0-103	Jog frequency	Setting range:0.00~600.00Hz	Factory value:5.00Hz
--------	---------------	-----------------------------	----------------------

After inverter receives Jog command, will run at setting frequency in the function code .

P0-104	Jog acceleration time	Setting range:0.1~3200.0s	Factory value:15.0s
P0-105	Jog deceleration time	Setting range:0.1~3200.0s	Factory value:15.0s

Set acceleration and deceleration time of jog run. This function code is 15.0s meaning that the accelerate time from 0Hz to 50Hz or the deceleration time from 50Hz to 0Hz.

P0-106	Skip frequency 1	Setting range:0.00~600.00Hz	Factory value:0.00Hz
P0-107	Skip frequency 2	Setting range:0.00~600.00Hz	Factory value:0.00Hz

## Detailed Function description

P0-108	Skip frequency 3	Setting range:0.00~600.00Hz	Factory value:0.00Hz
P0-109	Skip frequency bandwidth	Setting range:0.00~50.00Hz	Factory value:0.00Hz

By means of setting skip frequency, the inverter can keep away from the mechanical resonance with the load.

In order to avoid mechanical resonance point with the load, the inverter output frequency can jump run near the setting frequency . most 3 jump points can be defined.

Notice: Do not overlap 3jump frequency range or nesting set.




Chart 6-13 skip frequency run diagram

P0-110	Frequency arrive detecting range	Setting range:0.00~600.00Hz	Factory value:1.00Hz
--------	----------------------------------	-----------------------------	----------------------

With the use of multi-function output terminal. When difference of running frequency and setting frequency is less than setting value of function code, the output effective signal.




Chart 6-14 description of frequency arrive detecting range

P0-111	FDT level	Setting range:0.00~600.00Hz	Factory value:50.00Hz
P0-112	FDT delay value	Setting range:0.00~10.00Hz	Factory value:5.00Hz

With the use of multi-function output terminal. When running frequency is bigger than setting value of P0-111 Function Code, the output effective signal. P0-112 function code set detection hysteresis.




Chart 6-15 description of FDT level

P0-113	Starting delay time of auxiliary motor1	Setting range:0.1~600.0s	Factory value:15.0s
P0-114	Stopping delay time of auxiliary motor1	Setting range:0.1~600.0s	Factory value:15.0s

With the use of multi-function output terminal. When running frequency is Upper limit, and maintain setting value of the P0-113function code, the output



effective level; When running frequency is lower limit frequency, and maintain setting value of the P0-114function code, the output level is invalid; This function can be used to control a work-frequency motor start-stop, to achieve simple "one drag two function."




Chart 6-16 simple "one drag two function" description

### 6. 1. 11 Keyboard setting

P0-115	DIR/JOG function selection	Setting range:0~2	Factory value:0
--------	----------------------------	-------------------	-----------------

0: switching at running direction.

1: jog command. The key is a jog command.

2: The key is invalid.

P0-116	Keyboard STOP key function setting	Setting range:0~1	Factory value:0
--------	------------------------------------	-------------------	-----------------

0: It is invalid in the analog terminal / serial communication control mode.

1: It is effective in the analog terminal / serial communication control mode (equivalent to the external fault input).

P0-117	Default monitor parameters	Setting range:0~13	Factory value:0
--------	----------------------------	--------------------	-----------------

This function code is set for the default monitoring parameter in the fast-monitoring state.

0: Setting frequency; 1: Output frequency; 2: Output current; 3: Output voltage;  
 4: DC BUS voltage; 5: Running rotate speed; 6: Load rate; 7: Output power;  
 8: Output torque; 9: count of overheat due to Overload; 10: Inverter temperature;  
 11: PID closed loop setting; 12: PID closed loop feedback; 13: Display setting frequency when stopping; display  
 Output frequency in running.

### 6. 1. 12 Protect function setting

P0-118	Motor overload protection coefficient	Setting range:80.0%~110.0%	Factory value:100.0%
--------	---------------------------------------	----------------------------	----------------------

Overload protection is based on the motor rated current as the benchmark. When this function code 100.0%, the corresponding overload ability is: G-model at 150% motor rated current for one minute , P-model at 120% motor rated current for one minute , using inverse-time limit curve control. When this function code is 110.0%, the corresponding overload ability is: G-model at 165% motor rated current for one minute , P-model at 132% motor rated current for one minute , using inverse-time limit curve control.

P0-119	Pre-alarm value of motor overload	Setting range:100.0%~180.0%	Factory value:130.0%
--------	-----------------------------------	-----------------------------	----------------------

This 100.0% of function code corresponding to motor rated current. When the output current is higher than the value of this function code is set, output overload pre-alarm signal. This function is required to meet the use of multi-function output terminal .

P0-120	Over-current protection when lose speed	Setting range:110.0%~200.0%	Factoryvalue:Model option
--------	---	-----------------------------	---------------------------

This 100.0% of function code corresponding to rated current of motor.

The G-model (constant torque load) default value is 160.0%; the P-model (fan, pump model load) default value is 130.0%.

Surge current phenomenon of inverter will occur in the accelerating running process, due to acceleration time and motor inertia does not match or load inertia alters suddenly. By checking the inverter output current, and with this setting value of function code to compare, when the actual current exceeds the value, the Acc speed will be suspended until the current is reduced to less than the 5.0% of setting value.




Chart 6-17 Diagram of over-current protection when lose speed

P0-121	Over-current reducing frequency protection current	Setting range:110.0 % ~ 220.0%	Factory value:Model option
P0-122	Over-current reducing frequency delay time	Setting range:1~1000ms	Factory value:20ms

100.0% of P0-121 function code corresponding to rated current of motor. G-model (constant torque load) default value is 170.0%; P-model (fan, pump model load) default value is 140.0%. Surge current phenomenon of inverter will occur in running of constant speed (output frequency), due to the load alters suddenly.

By checking the inverter output current, and with P0-121 setting value to

compare, when the actual current exceeds the setting value of P0-121 and maintains setting time by P0-122 , the inverter will reduce the output frequency , until the current is reduced to less than the 5.0% of setting value , and then continue to accelerate to the setting output frequency.

Notice: In the traverse frequency running, the parameter is invalid.




Chart 6-18 Diagram of lower frequency limit current

P0-123	Over-voltage protection when lose speed	Setting range: 120.0%~150.0%	Factory value: 130.0%
--------	---	---------------------------------	--------------------------

This 100.0% of function code corresponding to the bus voltage 537 volts.

The surge phenomenon of inverter bus voltage will occur in the deceleration running process, due to deceleration time is set too short, does not match with the motor inertia. By detecting the bus voltage of inverter, and with the setting value of this function code to compare, when the actual bus voltage exceeds this value, the inverter will pause slow down until the bus voltage is reduced to less than the 5.0% of setting value , and then continue to slow down.

P0-124	Output open-phase protection function	Setting range:0~1	Factory value:0
--------	---------------------------------------	-------------------	-----------------

0: Invalid. Does not detect missing phase fault of output.

1: effective. Detect missing phase fault of output.

P0-125	Auto reset times	Setting range:0~3times	Factory value:0times
P0-126	Reset interval	Setting range:0.01~60.00s	Factory value:1.00s

Auto reset function can reset the fault in preset times (P0-125) and interval (P0-126). When P0-125 is set to be 0, it means “auto reset” is invalid, the protective device will be activated in case of fault, and the fault times will be cleared.

Notice: After normal running for 60s, the fault times occurred in the past will be cleared.

P0-127	Stop fault output selection during auto resetting	Setting range:0~1	Factory value:0
--------	---	-------------------	-----------------

effective.0: No action. Stop fault output is invalid.

1: Action. Stop fault output effective.

P0-128	Voltage value in under-voltage protection	Setting range:50.0%~85.0%	Factory value:75.0%
P0-129	Over-voltage protection point	Setting range:120.0%~150.0%	Factory value:140.0%

Set inverter under-voltage and over-voltage protection action levels. This 100.0% of function code corresponding for the bus voltage 537 volts.

When the inverter input three-phase power supply fluctuation is large, or load inertia is large, the frequent under-voltage and over-voltage fault occur, may be appropriate to adjust above 2 functions code.

P0-130	Dynamic braking voltg value	Setting range:110.0%~140.0%	Factory value:125.0%
--------	-----------------------------	-----------------------------	----------------------

Set brake threshold voltage value, 100.0% corresponding for the bus voltage 537 volts.

Dynamic braking means that inverter through connecting the built-in braking resistor or external braking resistor in order to expend the bus power of inverter, this method is effective to avoid the fault of bus over-voltage.

P0-131	Cooling fan control selection	Setting range:0~1	Factory value:0
--------	-------------------------------	-------------------	-----------------

0: running after Inverter run (according to the temperature of inverter automatically start and stop the fan).

1: running at all times.

### 6. 1. 13 Multi-step speed and simple PLC

P0-132	Terminals input mode of Muti-step speed	Setting range:0~1	Factory value:0
--------	---	-------------------	-----------------

0: combination form . By a binary combination form of multi-step speed terminal to select the 16-step speed of multi-step speed.

1: Non-combination form. By a non-combination form of multi-stage speed to select the 5-step speed of multi-stage speed.

Under combination form, the terminal 4 of multi-stage is lowest binary bit .

When the frequency source for the "VCI mode 2" or "CCI Model 2", it will not use the "multi-speed 0."

Muti-step speed terminal1	Muti-step speed terminal 2	Muti-step speed terminal 3	Muti-step speed terminal 4	Speed stage under combination form
OFF	OFF	OFF	OFF	Muti-step speed 0
OFF	OFF	OFF	ON	Muti-step speed 1
OFF	OFF	ON	OFF	Muti-step speed 2
OFF	OFF	ON	ON	Muti-step speed 3
OFF	ON	OFF	OFF	Muti-step speed 4
OFF	ON	OFF	ON	Muti-step speed 5
OFF	ON	ON	OFF	Muti-step speed 6
OFF	ON	ON	ON	Muti-step speed 7
ON	OFF	OFF	OFF	Muti-step speed 8
ON	OFF	OFF	ON	Muti-step speed 9

## Detailed Function description

Muti-step speed terminal1	Muti-step speed terminal 2	Muti-step speed terminal 3	Muti-step speed terminal 4	Speed stage under combination form
ON	OFF	ON	OFF	Muti-step speed10
ON	OFF	ON	ON	Muti-step speed 11
ON	ON	OFF	OFF	Muti-step speed 12
ON	ON	OFF	ON	Muti-step speed 13
ON	ON	ON	OFF	Muti-step speed 14
ON	ON	ON	ON	Muti-step speed 15

Chart 6-19 Diagram of multi-stage speed mode 0

Under non-compound form, the terminal 4 of multi-stage speed has highest priority, when it is effective, the other multi-stage speed terminal will be ignored.

Multi-step speed terminal 1	Multi-step speed terminal 2	Multi-step speed terminal 3	Multi-step speed terminal 4	Speed stage under non-combination form
OFF	OFF	OFF	OFF	Muti-step speed 0
ON	OFF	OFF	OFF	Muti-step speed 1
ignore	ON	OFF	OFF	Muti-step speed 2
ignore	ignore	ON	OFF	Muti-step speed 3
ignore	ignore	ignore	ON	Muti-step speed 4

Chart 6-20 Diagram of multi-step mode1

P0-133	Muti-step speed 0	Setting range:0.00~600.00Hz	Factory value:0.00Hz
P0-134	Muti-step speed 1	Setting range:0.00~600.00Hz	Factory value:1.00Hz
P0-135	Muti-step speed 2	Setting range:0.00~600.00Hz	Factory value:2.00Hz
P0-136	Muti-step speed 3	Setting range:0.00~600.00Hz	Factory value:3.00Hz
P0-137	Muti-step speed 4	Setting range:0.00~600.00Hz	Factory value:4.00Hz
P0-138	Muti-step speed 5	Setting range:0.00~600.00Hz	Factory value:5.00Hz
P0-139	Muti-step speed 6	Setting range:0.00~600.00Hz	Factory value:6.00Hz
P0-140	Muti-step speed 7	Setting range:0.00~600.00Hz	Factory value:7.00Hz
P0-141	Muti-step speed 8	Setting range:0.00~600.00Hz	Factory value:8.00Hz
P0-142	Muti-step speed 9	Setting range:0.00~600.00Hz	Factory value:9.00Hz
P0-143	Muti-step speed10	Setting range:0.00~600.00Hz	Factory value:10.00Hz
P0-144	Muti-step speed 11	Setting range:0.00~600.00Hz	Factory value:11.00Hz
P0-145	Muti-step speed 12	Setting range:0.00~600.00Hz	Factory value:12.00Hz

## Detailed Function description

P0-146	Muti-step speed 13	Setting range:0.00~600.00Hz	Factory value:13.00Hz
P0-147	Muti-step speed 14	Setting range:0.00~600.00Hz	Factory value:14.00Hz
P0-148	Muti-step speed 15	Setting range:0.00~600.00Hz	Factory value:15.00Hz

Set the frequency of multi-stage speed 16

P0-149	PLC run mode	Setting range:0~2	Factory value:0
--------	--------------	-------------------	-----------------

0: single-cycle. PLC cycle only once, after the Muti-step speed 15 has been finished , it will stop.

1: continuous cycle. PLC in cycles, after the Muti-step speed 15 has been finished , a new cycle will start from Muti-step speed 0.

2: running at Muti-step speed 15 after single-cycle .after the Muti-step speed 15 has been finished . running at Muti-step speed 15 at all times.

P0-150	Unit setting of PLC run times	Setting range:0~1	Factory value:0
--------	-------------------------------	-------------------	-----------------

0: second. The unit of PLC running time for second, set units ( P0-151 ~ P0-166 ).

1: hour. The unit of PLC running time for hour, set units (P0-151 ~ P0-166).

P0-151	0 <sup>th</sup> -step running time	Setting range:0.0~6553.5s (h)	Factory value:0.0s
P0-152	1 <sup>th</sup> -step running time	Setting range:0.0~6553.5s (h)	Factory value:0.0s
P0-153	2 <sup>th</sup> -step running time	Setting range:0.0~6553.5s (h)	Factory value:0.0s
P0-154	3 <sup>th</sup> -step running time	Setting range:0.0~6553.5s (h)	Factory value:0.0s
P0-155	4 <sup>th</sup> -step running time	Setting range:0.0~6553.5s (h)	Factory value:0.0s
P0-156	5 <sup>th</sup> -step running time	Setting range:0.0~6553.5s (h)	Factory value:0.0s
P0-157	6 <sup>th</sup> -step running time	Setting range:0.0~6553.5s (h)	Factory value:0.0s
P0-158	7 <sup>th</sup> -step running time	Setting range:0.0~6553.5s (h)	Factory value:0.0s
P0-159	8 <sup>th</sup> -step running time	Setting range:0.0~6553.5s (h)	Factory value:0.0s
P0-160	9 <sup>th</sup> -step running time	Setting range:0.0~6553.5s (h)	Factory value:0.0s
P0-161	10 <sup>th</sup> -step running time	Setting range:0.0~6553.5s (h)	Factory value:0.0s
P0-162	11 <sup>th</sup> -step running time	Setting range:0.0~6553.5s (h)	Factory value:0.0s



## Detailed Function description

P0-163	12 <sup>th</sup> -step running time	Setting range:0.0~6553.5s (h)	Factory value:0.0s
P0-164	13 <sup>th</sup> -step running time	Setting range:0.0~6553.5s (h)	Factory value:0.0s
P0-165	14 <sup>th</sup> -step running time	Setting range:0.0~6553.5s (h)	Factory value:0.0s
P0-166	15 <sup>th</sup> -step running time	Setting range:0.0~6553.5s (h)	Factory value:0.0s

Set running time of PLC per step.

P0-167	PLC Acc/Dec time setting1	Setting range:0~65535	Factory value:0
P0-168	PLC Acc/Dec time setting2	Setting range:0~65535	Factory value:0

Set acceleration and deceleration time of PLC per step, need to binary switching. binary number of 16-bit, the lowest bit for the BIT0, the highest for the BIT15.

Fncion code	Binary bit	PLCstep number	Acc/Dec time 0	Acc/Dec time 1	Acc/Dec time 2	Acc/Dec time 3
P0-167	BIT1 BIT0	0	00	01	10	11
P0-167	BIT3 BIT2	1	00	01	10	11
P0-167	BIT5 BIT4	2	00	01	10	11
P0-167	BIT7 BIT6	3	00	01	10	11
P0-167	BIT9 BIT8	4	00	01	10	11
P0-167	BIT11 BIT10	5	00	01	10	11
P0-167	BIT13 BIT12	6	00	01	10	11
P0-167	BIT15 BIT14	7	00	01	10	11
P0-168	BIT1 BIT0	8	00	01	10	11
P0-168	BIT3 BIT2	9	00	01	10	11
P0-168	BIT5 BIT4	10	00	01	10	11
P0-168	BIT7 BIT6	11	00	01	10	11
P0-168	BIT9 BIT8	12	00	01	10	11
P0-168	BIT11 BIT10	13	00	01	10	11
P0-168	BIT13 BIT12	14	00	01	10	11
P0-168	BIT15 BIT14	15	00	01	10	11

Chart 6-21 PLC Acc/Dec time selection

To select a group of Acc/Dec time by 2 binary bits, a total of four groups can be selected. Convert the 16-bit binary number to decimal number and set to the function code.

P0-169	PLC run direction setting	Setting range:0~65535	Factory value:0
--------	---------------------------	-----------------------	-----------------

Set the PLC running directions , need binary switching. A binary number of 16-bit, the lowest is the BIT0, highest is the BIT15.

BIT0 means that PLC 0<sup>th</sup>-step running direction. When BIT0=0, the 0<sup>th</sup>-step running direction is positive; when BIT0=1, the 0<sup>th</sup>-step running direction is opposite.

.....

BIT15 means that PLC 15<sup>th</sup>-step running direction. When BIT15=0, the 15<sup>th</sup>-step running direction is positive; when BIT15=1, the 15<sup>th</sup>-step running direction is opposite.

Convert the 16-bit binary number to decimal number and set to the function code.

### 6. 1. 14 PID control

P0-170	PID setting channels selection	Setting range:0~7	Factory value:0
--------	--------------------------------	-------------------	-----------------

0: keyboard digital setting. The PID setting is set by “P0-171” .

1: Keyboard potentiometers. The PID setting is set by keyboard potentiometer. Setting range is 0 ~ 10.00V.

2: VCI (0 ~ 10V). The PID setting is set by the VCI voltage of control terminal.

3:CCI(0~10V). The PID setting is set by the CCI voltage of control terminal. Input current is automatically converted into voltage, 20mA corresponds to 10V.

4:PULSE input setting. Internal conversion, pulse 10.00kHz converted to 10.00V.

5: PLC. Internal conversion, the setting frequency of PLC operation is converted to voltage, 10.00Hz corresponds to 10.00V.

6: serial communication settings. See the description of serial communication protocol.

7: CCI (4 ~ 20mA). The PID setting is set by the CCI current of control terminal. Note that CCI input jumper should select current input.

P0-171	PID Keyboard digital setting	Setting range:0.00~10.00V	Factory value:3.00V
--------	------------------------------	---------------------------	---------------------

Set PID number setting value.

P0-172	PID feedback channel selection	Setting range:0~6	Factory value:0
--------	--------------------------------	-------------------	-----------------

0: VCI (0 ~ 10V). The PID feedback is set by the VCI voltage of control terminal .

1:CCI(0~10V). The PID feedback is set by the CCI voltage of control terminal . Input current is automatically converted into voltage, 20mA corresponds to 10V.

2: MAX (VCI, CCI). VCI and CCI comparison, the large value as the PID feedback .

3:PULSE input setting. Internal conversion, pulse 10.00kHz converted to 10.00V.

4: Keyboard potentiometer (use when testing).

**5:CCI (4~20mA)** . The PID feedback is set by the CCI current of control terminal. Note that CCI input jumper should select current input.

6: VCI-CCI. The PID feedback is set by the value of subtracting between VCI and CCI voltage. This function is mainly used for difference in temperature

and pressure control.

P0-173	PID feedback channel gain	Setting range:0.10~10.00	Factory value:1.00
--------	---------------------------	--------------------------	--------------------

Set PID feedback gain

P0-174	PID feedback signal characteristic	Setting range:0~1	Factory value:0
--------	------------------------------------	-------------------	-----------------

0: positive characteristic. When the feedback value is bigger than PID setting, requires output frequency of the inverter to reduce in order to make PID balance.

1: inverse characteristic. When the feedback value is bigger than PID setting, requires output frequency of the inverter to rise in order to make PID balance.

P0-175	Proportional gain P	Setting range:0.00~10.00	Factory value:1.00
P0-176	Integral time I	Setting range:0.00~100.00s	Factory value:2.00s
P0-177	Differential time D	Setting range:0.00~100.00s	Factory value:0.00s

The proportion, integral, differential in PID regulator is independent of each other, through their respective codes to adjust the function.

The proportional gain P: the value is bigger means that the proportion regulation is stronger. This function code is 1.00 means when the deviation of PID setting and feedback is 10.00V , the output frequency command of PID regulator is 10.00Hz (ignore the role of integral and differential).

Notice: when the function code is 0, means that the proportional regulation t is prohibited.

Integral time I: the value is smaller means that the integral adjustment is stronger. This function code is 1.00s means when the deviation of PID setting and feedback is 10.00V , the output frequency command of PID regulator is 10.00Hz (ignore the role of proportion and differential).

Notice: when the function code is 0, means that the integral regulation is prohibited.

Differential time D: the value is larger means that the differential adjustment is stronger. This function code is 1.00s means when the change rate of deviation of PID setting and feedback is 10.00V within 1s, the output frequency command of PID regulator is 10.00Hz (ignore the role of proportion and integral).

Notice: when the function code is 0, means that the differential regulation is prohibited.

P0-178	Sampling cycle	Setting range:0.01~10.00s	Factory value:0.10s
--------	----------------	---------------------------	---------------------

Set the refresh cycles of setting and feedback value of PID regulator.

P0-179	Bias limit	Setting range:0.00~2.00V	Factory value:0.00V
--------	------------	--------------------------	---------------------

When the deviation value of PID setting and feedback is less than the value, then the PID stop operation, will maintain the output frequency

### 6. 1. 15 Traverse frequency setting

P0-180	Traverse amplitude	Setting range:0.0~100.0% (relative to setting frequency)	Factory value:0.0%
P0-181	Jitter frequency	Setting range:0.0~50.0% (relative to traverse amplitude)	Factory value:0.0%
P0-182	Rise time of traverse	Setting range:0.1~3200.0s	Factory value:15.0s
P0-183	Fall time of traverse	Setting range:0.1~3200.0s	Factory value:15.0s

Traverse frequency function applies to textile and chemical fiber industries.

When traverse frequency running, the output frequency of inverter will traverse up and down according to setting frequency as the center, in which raverse amplitude is set by P0-180, when the P0-180 is set to 0, the traverse

frequency running is invalid.

Notice: When the P0-180 set is too large, result in output frequency during traverse running will be higher than Upper limit, traverse running will be automatically invalid.




Chart 6-22 Traverse frequency run diagram

### 6. 1. 16 Serial Communication Settings

P0-184	Local address	Setting range:1~254	Factory value:1
--------	---------------	---------------------	-----------------

During serial communication, the identification address of inverter.

1~31, **33~254: address of slave inverter.**

32: address of master inverter (be used by many inverters at the same time).

P0-185	Baud rate	Setting range:0~4	Factory value:2
--------	-----------	-------------------	-----------------

Select data speed when serial communication.

0:2400bps; 1:4800bps; 2:9600bps; 3:19200bps; 4:38400bps.

P0-186	Data format	Setting range:0~2	Factory value:0
--------	-------------	-------------------	-----------------

0: 1 start bit,8 data bits,no parity check, 1 stop bit.

1: 1 start bit, 8 data bits, even parity check, 1 stop bit

2: 1 start bit, 8 data bits, odd parity check, 1 stop bit.

## Detailed Function description

P0-187	Responson delay	Setting range:1~150ms	Factory value:10ms
--------	-----------------	-----------------------	--------------------

After inverter receives data, first delay the setting time of function code and then send a response data duning serial communication.

### 6. 1. 17 Counter 、 timer function

When using the count function, “X-terminal” input filter times for P0-054 must be set to 1 .Clock cycles by counter clock input required is bigger than 4ms, the minimum pulse width is bigger than 1.5ms.

P0-188	Internal counter clock input frequency	Setting range:1~65535	Factory value:1
--------	--	-----------------------	-----------------

After the clock input of internal counter receives the signal, needs internal frequency operation then is summed up to the internal counter.

For example: when this parameter is set to 100, after the counter input had received 100 pulses , count value of internal counter is sumed up 1.

P0-189	Internal counter stetting value	Setting range:1~65535	Factory value:100
P0-190	Internal counter end value	Setting range:1~65535	Factory value:200

With the output terminal to use. When the count value of internal counter is bigger than the specified value, the output terminal will output the specified value of internal counter to reach the signal. When the count value of internal counter is equal to the end value, the output terminal will output the end value to reach the signal .

Notice: the counter is cleared may use the "internal counter reset" of terminal function.

For example: When the P0-188 is set to 2, P0-189 is set to 5, P0-190 is set to 9 , counting and signal diagram shown below.




Chart 6-23 Counting function diagram

P0-191	Internal timer unit	Setting range:0.01s~655.35s	Factory value:1.00s
P0-192	Internal timer cycle	Setting range:1~65535	Factory value:10

With the output terminal to use. When the internal timer reaches the cycle of timer, the output terminal will output the signal of the internal timer cycle reached. Time-cycle of timer is a product of parameter P0-191 and parameter P0-192.

Notice: You must use the "internal timer time enabled" of terminal function then the internal timer starts time. You can use the "internal timer reset" of terminal function to clear the timer.

For example: When the P0-191 is set to 0.1s, P0-192 is set to 5, the time-cycle of timer for  $0.1s \times 5 = 0.5s$ . Timing and signal diagram shown below.




Chart 6-24 Timing function diagram

### 6. 1. 18 Reserved for function group

The group is reserved parameter for software upgrades or custom parameter by customers.

P0-193	System locked	Setting range:0~50	Factory value:20
--------	---------------	--------------------	------------------



When motor no-load or light load, the surge current usually occurs. It is very serious thing when the motor power bigger than 30kW and the motor line more than 20 meters.

When the surge current occurs, it can be suppressed by adjusting the output frequency.

This parameter set this function, when this parameter is 0, it is invalid to control the surge current.

This parameter is bigger so that the function is stronger, but the speed wave may be bigger .

P0-194	judgement value of Under-voltage pre-warning	Setting range:50.0 % ~ 100.0%	Factory value:80.0 %
--------	--	-------------------------------	----------------------

With the use of multi-function output terminal. This function code 100.0% corresponding to the bus voltage 537 volts.

When the bus voltage less than the setting value, the signal of under-voltage and pre-warning will be output; when the bus voltage rises to the value bigger than the 5.0%setting value, it will stop output the signal of under-voltage and pre-warning.

P0-195	AO1 output bias	Setting range:0.00~10.00V	Factory value:0.00V
--------	-----------------	---------------------------	---------------------

Set AO1 minimum output value. Can achieve 2 ~ 10V output with P0-077. (P0-077 = 0.8, P0-195 = 2.00)

P0-196	AO2 output bias	Setting range:0.00~10.00V	Factory value:0.00V
--------	-----------------	---------------------------	---------------------

Set AO2 minimum output value. can achieve the 4 ~ 20mA output with P0-078. (P0-078 = 0.8, P0-196 = 2.00)

P0-197	Min input of keypad poentionmeter	Setting range:0.00~5.00V	Factory value:0.00V
--------	-----------------------------------	--------------------------	---------------------

## Detailed Function description

P0-198	Max input of Keypad poentionmeter	Setting range:0.00~5.00V	Factory value:5.00V
P0-199	filter coefficient of keypad potentiometer	Setting range:1~12	Factory value:6

When the keyboard line is bigger than 10 meters, the power supply of keyboard potentiometer will be low, the setting frequency will be affected. can amend this shortcoming through the relevant parameters.

When the keyboard setting can not be adjusted to 0hz , to increase P0-197.

When the keyboard setting can not be adjusted to 50hz ,to reduce P0-198.

When the keyboard setting waves, to increase P0-199.

P0-200	VCI input bias	Setting range:0.00~1.00V	Factory value:0.30V
P0-201	CCI input bias	Setting range:0.00~1.00V	Factory value:0.30V

This parameter is used to adjust the input bias of analog input channels. When the VCI or the CCI does not connected analog input, adjust the value so that the monitoring value of VCI or CCI (d3-003, d3-004) is 0.

### 6. 1. 19 Function Code modify setting

P0-205	Function code initialization	Setting range:0~65535	Factory value:0
--------	------------------------------	-----------------------	-----------------

0: No action.

1: Initialization for the factory default values. P0 function group renews to factory state.

555: Initialization for the user default values. P0 function group renews to the " saving region of user"

777: Save the current function code for the user default value. P0 function group save to the " saving region of user ".

999: Initialize EPP. P0 function group and the " saving region of user " renew to factory state.

P0-206	Function code writing protection	Setting range:0~1	Factory value:0
--------	----------------------------------	-------------------	-----------------

0: Invalid. P0 function group can modify.

1: effective. P0 function group can be modified only by the function code, other functions can not modify it.

## 6.2 P1 function groups (supplier setting function code)

P1-000	supplier password	Setting range:0~65535	Factory value:Model option
--------	-------------------	-----------------------	----------------------------

This function code is password input, if the password is wrong, will not be able to access other functions code of P1 function groups.

P1-001	Mode option	Setting range:0~2	Factory value:0
--------	-------------	-------------------	-----------------

0: G-model. Overload ability is 150% rated current 60s; 180% rated current 2s.

1: P-model. Overload ability is 120% rated current 60s; 150% rated current 2s.

2: Z-model. Overload ability is 150% rated current 60s; 180% rated current 2s.

P1-002	Clear working time and fault record	Setting range:0~1	Factory value:0
--------	-------------------------------------	-------------------	-----------------

0: No action.

1: Clear the accumulated hours of work and fault records.

P1-003	Use time-limit setting (hour)	Setting range:0~65535h	Factory value:Model option
--------	-------------------------------	------------------------	----------------------------

0: mean that there is no use time-limit.

1 ~ 65535: set the use time-limit, when the working time of inverter is more than this value, the inverter will stop work.

## 6.3 d0 function groups (read only)

d function groups are divided into four parts (d0, d1, d2, d3), display the historical fault information、inverter information、running status of inverter、the user interface status respectively, please look over "Function Code List."

## **7 Fault and trouble shooting**

### **7.1 Fault and alarm**

Fault and alarm are abnormal working status of inverter. But both have obvious distinguish.

Inverter in running for self-monitoring. If fault issued, fault code of inverter will be displayed, and the inverter output will be shut down, result in the motor in a free-running state until stopping; If alarm issued, alarm code of inverter will be displayed, the inverter output will be not shut down, and the motor still is controlled by the inverter.

#### **7.1.1 Fault Indication and Fault Reset**

E001~E015 for fault indications.

Fault reset of inverter has many ways: operate the "reset key" of keyboard、terminal reset function, or, if necessary, shut off the main power supply for some time can make fault reset. If the fault has disappeared, inverter will resume normal operation; if the fault still exists, inverter will be tripped again.

Notice: If the jump-start command is effective, fault reset will jump-start transmission equipment.

#### **7.1.2 Alarm indication and alarm reset**

E030 for alarm indication.

The inverter can realize alarm reset only by "ESC key" of operation keyboard.

### **7.2 Fault and trouble shooting**

## Fault and trouble shooting

Code	Model	Reason	Solution
E001	Over-current fault	Acc/Dec time is too short. Inverter power is too small. Voltage is too low.	Increase Acc/Dec time. Select bigger capacity inverter. Inspect input voltage.
E002	Power module fault	Acc/Dec time is too short. Short-circuit on output side of inverter. Power module damaged. Exterior disturbances.	Increase Acc/Dec time. Inspect motor insulation. Ask for support. Inspect external equipment if has strong interference source.
E003	DC bus over-voltage fault	Dec time is too short and regenerative energy from the motor is too large. Network voltage is too high. Load is too heavy and regenerative energy is too large.	Extend the Dec time. Inspect input voltage. Select bigger capacity inverter
E004	DC bus under-voltage fault	Network voltage is too low.	Inspect input voltage.
E005	Motor over-load fault	Network voltage is too low. Load is too heavy. Motor rated current setting is incorrect. Inverter power is too small.	Inspect input voltage. Check the load, adjust the amount of torque to enhance. Reinstall rated current of the motor. Select bigger capacity inverter
E006	Inverter over-heat fault	Ambient temperature is too high. Inverter airiness is badness. Cooling fans of inverter stop or damaged Detection circuit of temperature damaged	Install colling unit. To improve the ventilation. Check or replace cooling fans Ask for support.
E007	Soft Startup fault	Soft startup circuit or contactor damaged	Ask for support.
E008	Input phase fault	Open-phase occurred in three-phase AC input	Check input power and wiring.
E009	Output phase fault	Current asymmetry on three-phase	Check output wiring and motor

## Fault and trouble shooting

Code	Model	Reason	Solution
		input side .	insulation.
E010	External fault	Input terminals of external fault signal take effect. Keyboard “stop key” is set as an emergency stop .	Check the cause. Check the setting of keyboard“stop key”.
E011	Use time arrived fault	Use time arrived by Supplier setting.	Contact with the supplier.
E012	Current detection circuit fault	Current detection device is damaged.	Ask for support.
E013	EEPROM failure to read and write	Control board parts are damaged. External disturbances.	Ask for support. Inspect external equipment if has strong interference source.
E014	Motor parameter detection fault	Deviation of the actual value and the theoretical value is too large. Motor parameter setting is Incorrect.	Affirm the motor in no-load state . Check the setting of motor parameter.
E015	CPU is disturbed fault	External disturbances	Inspect external equipment if has strong interference source.
E030	Operation error alarm	This is a alarm, inverter output is not turn-off. Function code is locked Function code is prohibited to modify.	Press the"ESC key" exit alarm state. Check P0-206 function code Settings. The function code is ptohibited to modify in running.

Chart 7-1 fault and trouble shooting

### 7.3 Common faults and solutions

Inverter may have following faults or malfunctions during operation, reference the following solutions.

#### 7.3.1 No display after power on:

1. Inspect if the voltage of power supply and the rated voltage of inverter is consistent with multi-meter. If the power supply has problem,

inspect and solve it.

2. Inspect whether the three-phase rectify bridge is in good condition or not.
3. Check the CHARGE light.
4. If the above are normal, the fault may lie part of the switching power supply. Please ask for support.

### **7.3.2 Motor doesn't move after inverter running**

1. For the motor has brake device, make sure that motor is not in a brake condition.
2. Disconnect the inverter and the motor wiring, run inverter in 50Hz, inspect if there is balanced three-phase output among U, V, W with multi-meter, notice: due to U, V, W phase between is a high-frequency pulse, please use analog voltage meter to measure(range for AC 500V). If the voltage is not balanced or no voltage, the inverter module is damaged. Please ask for support.
3. If the above are normal. Please ask for support.

## 8 Maintenance

### 8.1 Inspect the inverter periodically

On account of the change of inverter using environment , such as temperature、humidity、fog and other effects, as well as the internal components of inverter are aging and other factors that could cause a variety of faults. Thus, during in storage and use of inverter must be carried out daily inspections and maintain the inverter periodically.

Items to be checked	Inspection contents	Methods
Terminals and screws	Whether all screws be tightened	tighten them with a screwdriver
Radiator disc	No dust	with a vacuum cleaner in 4 ~ 6kg/cm <sup>2</sup> pressure blow off
PCB	No dust	with a vacuum cleaner in 4 ~ 6kg/cm <sup>2</sup> pressure blow off
Cooling fan	smooth operation and no vibration	Replace cooling fan
Power Components	No dust	with a vacuum cleaner in 4 ~ 6kg/cm <sup>2</sup> pressure blow off
Electrolytic capacitors	Whether change colour 、 peculiar smell、 bubbling	Replace

Chart 8-1 Inspect the inverter periodically

### 8.2 Replacement of wearing parts

Fans and electrolytic capacitors are wearing parts, please make periodic replacement to ensure long term, In the less than 30 °C ambient temperature, load rate 80% or less, run rate of 12 hours / day cases, The replacement periods are as follows:

1. Fan: Must be replaced when using up to 3 years;



2. Electrolytic Capacitor: Must be replaced when using up to 5 years.

### **8.3 Warranty description**

The manufacturer warrants its products from the date of purchase. Manufacturer is responsible only for quality problems is caused by product design and production process, it is not responsible for the products were damaged in the course of transportation or discharge box. For the incorrect installation and use,such as temperature, dust, corrosion and other non-compliance of the working conditions and overload operation , manufacturer is irresponsible.

## 9 List of Function Parameters

× indicates that this parameter cannot be modified during running. ○ indicates that this parameter can be modified during running. Address items for the MODBUS register address.

### 9.1 P0 function groups (users setup function code)

Code	Function name	Setting range	Units	Factory setting	Modify	Address
Basic Function						
P0-000	Speed control mode	0:VVVF control 1:Vector control	1	0	×	000H
P0-001	Select command source	0:Keypad 1:Terminal 2:Communication	1	0	○	001H
P0-002	Select frequency source	0:main frequency source x 1:Auxiliary frequency source Y 2:main frequency source x + Auxiliary frequency source y 3:max(main frequency source x, Auxiliary frequency source y) 4:be confirmed by selection terminal of frequency source.	1	0	○	002H
P0-003	Main frequency source x selection	0:keyboard poentionmeter 1:keyboard digital setting (UP、DOWN) 2:VCI 3:CCI 4:simple PLC	1	0	○	003H

## List of Function Parameters

Code	Function name	Setting range	Units	Factory setting	Modify	Address
P0-004	Auxiliary frequency source Y selection	5:multi-step speed 6:PID 7:PULSE 8:communication 9:VCI mode2 10:CCLmode2	1	0	○	004H
P0-005	Main frequency source X gain	0.10~10.00	0.01	1.00	○	005H
P0-006	Auxiliary frequency source Y gain	0.10~10.00	0.01	1.00	○	006H
P0-007	Digital setting of frequency of keyboard	0.00~600.00Hz	0.01Hz	50.00Hz	○	007H
P0-008	Keyboard and terminal UP/DOWN setting	0:invalid 1:effective, power off no saving 2:effective, power off saving	1	1	×	008H
P0-009	Running direction control	0:setting direction same 1:setting direction reverse 2:forbid reverse	1	0	×	009H
P0-010	Upper frequency limit	Lower limit ~ 600.00Hz	0.01Hz	50.00Hz	○	00AH
P0-011	Lower frequency limit	0.00Hz~upper limit	0.01Hz	0.00Hz	○	00BH
P0-012	Acc time0	0.1~3200.0s	0.1s	15.0s	○	00CH
P0-013	Dec time0	0.1~3200.0s	0.1s	15.0s	○	00DH
P0-014	Carrier frequency	1.0~10.0KHz	0.1KHz	4.0KHz	○	00EH
P0-015	Carrier frequency adjust selection	0: fixed PWM, carrier temperature adjust is invalid 1: fixed PWM,carrier temperature adjust is effective 2:Random	1	Model option	○	00FH

## List of Function Parameters

Code	Function name	Setting range	Units	Factory setting	Modify	Address
		PWM,carrier temperature adjust is invalid 3:Random PWM,carrier temperature adjust is effective				
Motor parameter						
P0-016	Motor rated power	0.4 ~ 1000.0KW (Model option)	0.1KW	Model option	×	010H
P0-017	Motor rated frequency	1.00~600.00Hz	0.01Hz	50.00Hz	×	011H
P0-018	Motor rated voltage	10.0~440.0V (Model option)	0.1V	Model option	×	012H
P0-019	Motor rated current	1.0~2000.0A (Model option)	0.1A	Model option	×	013H
P0-020	Motor rated rotation speed	5~30000rpm	1rpm	1460rmp	×	014H
P0-021	Motor no load current	10.0~100.0%	0.1%	40.0%	○	015H
P0-022	Stator resistance	0.001~65.000Ω	0.001Ω	Model option	○	016H
P0-023	reserved				○	017H
P0-024	reserved				○	018H
P0-025	Reserved				○	019H
P0-026	Motor parameters autotuning	0:invaide 1:Rotatation test 2:Static test	1	0	×	01AH
VVVF control parameter						
P0-027	V/F curve setting	0:linear minus 1:1.3(order) 2:1.7 (order) 3:2.0 (order) 4:High torque curve 1 5:High torque curve 2 6:High torque curve3 7:Four points curve	1	0	×	01BH
P0-028	V/F voltage point 0	0.0~15.0%	0.1%	1.0%	×	01CH

## List of Function Parameters

Code	Function name	Setting range	Units	Factory setting	Modify	Address
P0-029	V/F frequency point 1	0.0~100.0%	0.1%	40.0%	×	01DH
P0-030	V/F voltage point 1	0.0~100.0%	0.1%	40.0%	×	01EH
P0-031	V/F frequency point 2	0.0~100.0%	0.1%	80.0%	×	01FH
P0-032	V/F voltage point 2	0.0~100.0%	0.1%	80.0%	×	020H
P0-033	Automatic torque compensation gain	0.0~250.0%	0.1%	100.0%	○	021H
P0-034	Automatic torque compensation filter	0.01~5.00s	0.01s	0.10s	○	022H
P0-035	Automatic slip compensation gain	0.0~250.0%	0.1%	0.0%	○	023H
P0-036	Auto slip compensation Filter time	0.01~5.00s	0.01s	0.10s	○	024H
P0-037	AVR function	0:invalid 1:still effective 2:invalid only during Dec speed until having stopped	1	2	×	025H
P0-038	Saving energy run	0:invalid; 1:effective	1	0	○	026H
P0-039	Saving energy running Voltage limit	20.0~100.0%	0.1%	80.0%	○	027H
Vector Control parameter						
P0-040	ASR gain	50.0~200.0%	0.1%	100.0%	○	028H
P0-041	ASR filter	0.01~1.00s	0.01s	0.10s	○	029H
P0-042	Current-loop gain	50.0~200.0%	0.1%	100.0%	○	02AH
P0-043	Current-loop filter	0.01~1.00s	0.01s	0.10s	○	02BH
P0-044	Vc torque compensation gain	50.0~250.0%	0.1%	100.0%	○	02CH
P0-045	VC Slip compensation gain	50.0~250.0%	0.1%	100.0%	○	02DH
Input terminals						

## List of Function Parameters

Code	Function name	Setting range	Units	Factory setting	Modify	Address
P0-046	X1 terminal function	0:invalid 1:Forward 2:Reverse 3:3-wire control 4:Reset fault 5:UP command	1	1	×	02EH
P0-047	X2 terminal function	6:DOWN command 7:JOG forward 8:JOG reverse 9:Coast to stop 10:External fault input	1	2	×	02FH
P0-048	X3 terminal function	11:Acc/Dec speed Pause 12:PLC run reset 13:PLC pause 14:traverse run reset 15:traverse pause	1	7	×	030H
P0-049	X4 terminal function	16:PID operation pause 17:Clear PID integral time 18:switch command source	1	8	×	031H
P0-050	X5 terminal function	19:Frequency selection 1 20:Frequency selection 2 21:Acc/dec speed 1 22:Acc/dec speed 2	1	23	×	032H
P0-051	X6 terminal function	23:Muti-step speed terminal 1 24:Muti-step speed terminal 2 25:Muti-step speed terminal 3	1	24	×	033H
P0-052	X7 terminal function	26:Muti-step speed terminal 4 27:Internal counter clock	1	25	×	034H

## List of Function Parameters

Code	Function name	Setting range	Units	Factory setting	Modify	Address
P0-053	X8 terminal function	input 28:Reset internal counter 29:Enabled internal timer 30: Reset internal timer	1	26	×	035H
P0-054	X input filter times	1~50	1	20	○	036H
P0-055	Control mode of terminal	0: 2-wire mode 1 1: 2-wire mode 2 2: 3-wire mode 1 3: 3-wire mode 2	1	0	×	037H
P0-056	UP/DOWN range	0.01~100.00Hz/s	0.01Hz/s	10.00Hz/s	○	038H
P0-057	VCI min input	0.00~10.00V	0.01V	0.00V	○	039H
P0-058	VCI min input corresponding frequency	0.00~600.00Hz	0.01Hz	0.00Hz	○	03AH
P0-059	VCI max input	0.00~10.00V	0.01V	10.00V	○	03BH
P0-060	VCI max input corresponding frequency	0.00~600.00Hz	0.01Hz	50.00Hz	○	03CH
P0-061	VCI input filter time	0.01~5.00s	0.01s	0.10s	○	03DH
P0-062	CCI min input	0.00~10.00V	0.01V	0.00V	○	03EH
P0-063	CCI min input corresponding frequency	0.00~600.00Hz	0.01Hz	0.00Hz	○	03FH
P0-064	CCI max input	0.00~10.00V	0.01V	10.00V	○	040H
P0-065	CCI max input corresponding frequency	0.00~600.00Hz	0.01Hz	50.00Hz	○	041H
P0-066	CCI input filter time	0.01~5.00s	0.01s	0.10s	○	042H
P0-067	PULSE min input	0.00~50.00KHz	0.01KHz	0.00KHz	○	043H
P0-068	PULSE min input corresponding frequency	0.00~600.00Hz	0.01Hz	0.00Hz	○	044H
P0-069	PULSE max input	0.00~50.00KHz	0.01KHz	50.00KHz	○	045H
P0-070	PULSE max input corresponding	0.00~600.00Hz	0.01Hz	50.00Hz	○	046H

List of Function Parameters

Code	Function name	Setting range	Units	Factory setting	Modify	Address
	frequency					
P0-071	PULSE input filter time	0.01~5.00s	0.01s	0.10s	○	047H
Output terminals						
P0-072	Relay output selection	0: Invalid 1: stop fault in running 2: inverter running 3: run frequency arrived setting value 4: Upper limit frequency running 5: Lower limit frequency running	1	1	×	048H
P0-073	Y1 output selection	6: Inverter running at zero speed 7: FTD reached 8: Overload pre-warning	1	2	×	049H
P0-074	Y2 output selection	9: Slight fault during running 10: inverter ready 11: External fault stop 12: stop in Running under voltage 13: Forward running 14: Reverse running 15: Auxiliary motor 16: Appoint value of internal counter reached 17: end-value of internal counter arrived. 18: end-value of internal timer arrived. 19: alarm for under voltage	1	3	×	04AH



## List of Function Parameters

Code	Function name	Setting range	Units	Factory setting	Modify	Address
P0-075	AO1 output selection	0: Output frequency 1: Output current 2: Output voltage 3: Setting frequency	1	0	○	04BH
P0-076	AO2 output selection	4: DC BUS voltage 5: VCI input voltage 6: CCI input voltage 7: PULSE input	1	1	○	04CH
P0-077	AO1 output gain	0.10~10.00	0.01	1.00	○	04DH
P0-078	AO2 output gain	0.10~10.00	0.01	1.00	○	04EH
<b>Start and stop control</b>						
P0-079	Start mode	0: Starting frequency 1: DC brake before start 2: Rotate speed tracking start	1	0	○	04FH
P0-080	Starting frequency	0.00~10.00Hz	0.01Hz	0.00Hz	○	050H
P0-081	Hold time of starting frequency	0.00~60.00s	0.01s	0.00s	○	051H
P0-082	start DC Braking current	0.0~150.0%	0.1%	0.0%	○	052H
P0-083	start DC Braking time	0.0~60.00s	0.01s	0.00s	○	053H
P0-084	Start mode of REV tracking	0: Start by setting frequency 1: Start by upper limit frequency	1	0	○	054H
P0-085	Stop mode	0: DEC stop 1: Coast to stop	1	0	○	055H
P0-086	frequency of DC braking	0.00~50.00Hz	0.01Hz	0.00Hz	○	056H
P0-087	Waiting time before DC braking	0.01~60.00s	0.01s	0.01s	○	057H
P0-088	DC braking current	0.0~150.0%	0.1%	0.0%	○	058H

## List of Function Parameters

Code	Function name	Setting range	Units	Factory setting	Modify	Address
P0-089	DC braking time	0.0~60.00s	0.01s	0.00s	○	059H
P0-090	Dead of time FWD/REV	0.01~60.00s	0.01s	0.50s	○	05AH
P0-091	Restart after power off instantaneous	0:invalid; 1:effective	1	0	○	05BH
P0-092	waiting time for restart	0.01~60.00s	0.01s	0.10s	○	05CH
P0-093	least output frequency setting ( setting frequency less than lower limit frequency)	0: Running at the Frequency is limited 1:dormancy Stand-by (0Hz output)	1	0	○	05DH
Acc/Dec assistant						
P0-094	Acc/Dec mode selection	0: Linear Acc/Dec 1:S curve Acc/Dec	1	0	○	05EH
P0-095	S curve acceleration characteristic time	0.2~2.0s	0.1s	0.5s	○	05FH
P0-096	S curve deceleration characteristic time	0.2~2.0s	0.1s	0.5s	○	060H
P0-097	ACC time 1	0.1~3200.0s	0.1s	15.0s	○	061H
P0-098	DEC time 1	0.1~3200.0s	0.1s	15.0s	○	062H
P0-099	ACC time 2	0.1~3200.0s	0.1s	15.0s	○	063H
P0-100	DEC time 2	0.1~3200.0s	0.1s	15.0s	○	064H
P0-101	ACC time 3	0.1~3200.0s	0.1s	15.0s	○	065H
P0-102	DEC time 3	0.1~3200.0s	0.1s	15.0s	○	066H
Auxiliary function						
P0-103	Jog frequency	0.00~600.00Hz	0.01Hz	5.00Hz	○	067H
P0-104	Jog acceleration time	0.1~3200.0s	0.1s	15.0s	○	068H
P0-105	Jog deceleration time	0.1~3200.0s	0.1s	15.0s	○	069H
P0-106	Skip frequency 1	0.00~600.00Hz	0.01Hz	0.00Hz	○	06AH
P0-107	Skip frequency 2	0.00~600.00Hz	0.01Hz	0.00Hz	○	06BH
P0-108	Skip frequency 3	0.00~600.00Hz	0.01Hz	0.00Hz	○	06CH
P0-109	Skip frequency bandwidth	0.00~50.00Hz	0.01Hz	0.00Hz	○	06DH
P0-110	Frequency arrive detecting range	0.00~600.00Hz	0.01Hz	1.00Hz	○	06EH
P0-111	FDT level	0.00~600.00Hz	0.01Hz	50.00Hz	○	06FH

List of Function Parameters

Code	Function name	Setting range	Units	Factory setting	Modify	Address
P0-112	FDT delay value	0.00~10.00Hz	0.01Hz	5.00Hz	○	070H
P0-113	Starting delay time Of auxiliary motor1	0.1~600.0s	0.1s	15.0s	○	071H
P0-114	Stopping delay time of auxiliary motor1	0.1~600.0s	0.1s	15.0s	○	072H
Keyboard setting						
P0-115	DIR/JOG function selection	0:Running direction switch 1:JOG command 2: Invalid	1	0	○	073H
P0-116	Keyboard STOP key function setting	0:Invalid,when controlling by analog terminals /communication 1:effective,when controlling by analog terminals /communication ( be equal external fault input)	1	0	○	074H
P0-117	Default monitor parameters	0:Setting frequency 1: Output frequency 2: Output current 3: Output voltage 4: DC BUS voltage 5:Running rotate speed 6: Load rate 7: Output power 8: Output torque 9:count of overheat due to Overload 10:Inverter temperature (part of model reserved) 11:PID closed loop setting 12:PID closed loop feedback 13: Display	1	0	○	075H

## List of Function Parameters

Code	Function name	Setting range	Units	Factory setting	Modify	Address
		setting frequency when stopping; display Output frequency in running.				
Protect function setting						
P0-118	Motor overload protection coefficient	80.0 % ~ 110.0 % (rated current of motor)	0.1%	100.0%	○	076H
P0-119	Pre-alarm value of motor overload	100.0 % ~ 180.0 % (rated current of motor)	0.1%	130.0%	○	077H
P0-120	Over-current protection when lose speed	110.0%~200.0%	0.1%	Model option	○	078H
P0-121	Over-current reducing frequency protection current	110.0%~220.0%	0.1%	Model option	○	079H
P0-122	Over-current reducing frequency delay time	1~1000ms	1ms	20ms	○	07AH
P0-123	Over-voltage protection when lose speed	120.0%~150.0%	0.1%	130.0%	○	07BH
P0-124	Output open-phase Protection function	0:invalid; 1:effective	1	0	○	07CH
P0-125	Auto reset times	0~3times	1times	0times	○	07DH
P0-126	Reset interval	0.01~60.00s	0.01s	1.00s	○	07EH
P0-127	Stop fault output selection during auto resetting	0:no action 1:action	1	0	○	07FH
P0-128	Voltage value in under-voltage protection	50.0%~85.0%	0.1%	75.0%	○	080H
P0-129	Over-voltage protection point	120.0%~150.0%	0.1%	140.0%	○	081H
P0-130	Dynamic braking voltag value	110.0%~140.0%	0.1%	125.0%	○	082H
P0-131	Cooling fan control	0: Auto stop mode	1	0	○	083H

## List of Function Parameters

Code	Function name	Setting range	Units	Factory setting	Modify	Address
	selection	1: Always working				
Multi-stage speed and simple PLC						
P0-132	Terminals input mode of Multi-step speed	0: Binary combination format 1: No combination format	1	0	○	084H
P0-133	Muti-step speed 0	0.00~600.00Hz	0.01Hz	0.00Hz	○	085H
P0-134	Muti-step speed 1	0.00~600.00Hz	0.01Hz	1.00Hz	○	086H
P0-135	Muti-step speed 2	0.00~600.00Hz	0.01Hz	2.00Hz	○	087H
P0-136	Muti-step speed 3	0.00~600.00Hz	0.01Hz	3.00Hz	○	088H
P0-137	Muti-step speed 4	0.00~600.00Hz	0.01Hz	4.00Hz	○	089H
P0-138	Muti-step speed 5	0.00~600.00Hz	0.01Hz	5.00Hz	○	08AH
P0-139	Muti-step speed 6	0.00~600.00Hz	0.01Hz	6.00Hz	○	08BH
P0-140	Muti-step speed 7	0.00~600.00Hz	0.01Hz	7.00Hz	○	08CH
P0-141	Muti-step speed 8	0.00~600.00Hz	0.01Hz	8.00Hz	○	08DH
P0-142	Muti-step speed 9	0.00~600.00Hz	0.01Hz	9.00Hz	○	08EH
P0-143	Muti-step speed10	0.00~600.00Hz	0.01Hz	10.00Hz	○	08FH
P0-144	Muti-step speed 11	0.00~600.00Hz	0.01Hz	11.00Hz	○	090H
P0-145	Muti-step speed 12	0.00~600.00Hz	0.01Hz	12.00Hz	○	091H
P0-146	Muti-step speed 13	0.00~600.00Hz	0.01Hz	13.00Hz	○	092H
P0-147	Muti-step speed 14	0.00~600.00Hz	0.01Hz	14.00Hz	○	093H
P0-148	Muti-step speed 15	0.00~600.00Hz	0.01Hz	15.00Hz	○	094H
P0-149	PLC run mode	0: Stop after one cycle 1: continuous cycle 2: running according to 15 <sup>th</sup> -step after one cycle	1	0	×	095H
P0-150	Unit setting of PLC run times	0: Second 1: Hour	1	0	×	096H
P0-151	0 <sup>th</sup> -step running time	0.0~6553.5s (h)	0.1s	0.0s	○	097H
P0-152	1 <sup>th</sup> -step running time	0.0~6553.5s (h)	0.1s	0.0s	○	098H
P0-153	2 <sup>th</sup> -step running time	0.0~6553.5s (h)	0.1s	0.0s	○	099H
P0-154	3 <sup>th</sup> -step running time	0.0~6553.5s (h)	0.1s	0.0s	○	09AH
P0-155	4 <sup>th</sup> -step running time	0.0~6553.5s (h)	0.1s	0.0s	○	09BH
P0-156	5 <sup>th</sup> -step running time	0.0~6553.5s (h)	0.1s	0.0s	○	09CH
P0-157	6 <sup>th</sup> -step running time	0.0~6553.5s (h)	0.1s	0.0s	○	09DH

## List of Function Parameters

Code	Function name	Setting range	Units	Factory setting	Modify	Address
P0-158	7 <sup>th</sup> -step running time	0.0~6553.5s (h)	0.1s	0.0s	○	09EH
P0-159	8 <sup>th</sup> -step running time	0.0~6553.5s (h)	0.1s	0.0s	○	09FH
P0-160	9 <sup>th</sup> -step running time	0.0~6553.5s (h)	0.1s	0.0s	○	0A0H
P0-161	10 <sup>th</sup> -step running time	0.0~6553.5s (h)	0.1s	0.0s	○	0A1H
P0-162	11 <sup>th</sup> -step running time	0.0~6553.5s (h)	0.1s	0.0s	○	0A2H
P0-163	12 <sup>th</sup> -step running time	0.0~6553.5s (h)	0.1s	0.0s	○	0A3H
P0-164	13 <sup>th</sup> -step running time	0.0~6553.5s (h)	0.1s	0.0s	○	0A4H
P0-165	14 <sup>th</sup> -step running time	0.0~6553.5s (h)	0.1s	0.0s	○	0A5H
P0-166	15 <sup>th</sup> -step running time	0.0~6553.5s (h)	0.1s	0.0s	○	0A6H
P0-167	PLC Acc/Dec time setting1	0~65535 (Binary bit conversion)	1	0	○	0A7H
P0-168	PLC Acc/Dec time setting2	0~65535 (Binary bit conversion)	1	0	○	0A8H
P0-169	PLC run direction setting	0~65535 (Binary bit conversion)	1	0	○	0A9H
<b>PID control</b>						
P0-170	PID setting channels selection	0:Keyboard digital setting 1:Keyboard poentionmeter 2:VCI 3:CCI 4:PULSE input 5:PLC 6:Communication 7:CCI (4~20mA)	1	0	○	0AAH
P0-171	PID Keyboard digital setting	0.00~10.00V	0.01V	3.00V	○	0ABH
P0-172	PID feedback selection	0:VCI (0~10V) 1:CCI (0~10V) 2:MAX(VCI,CCI) 3: PULSE input	1	0	○	0ACH

## List of Function Parameters

Code	Function name	Setting range	Units	Factory setting	Modify	Address
		4:Keyboard poentionmeter (testing) 5:CCI (4~20mA) 6:VCI-CCI				
P0-173	PID feedback channel gain	0.10~10.00	0.01	1.00	○	0ADH
P0-174	PID feedback signal characteristic	0: Positive ; 1: Negative	1	0	○	0AEH
P0-175	Proportional gain P	0.00~10.00	0.01	1.00	○	0AFH
P0-176	Integral time I	0.00 (no integral) ~ 100.00s	0.01s	2.00s	○	0B0H
P0-177	Differential time D	0.00 (no differential) ~ 100.00s	0.01s	0.00s	○	0B1H
P0-178	Sampling cycle	0.01~10.00s	0.01s	0.10s	○	0B2H
P0-179	Bias limit	0.00~2.00V	0.01V	0.00V	○	0B3H
<b>Traverse frequency setting</b>						
P0-180	Traverse amplitude	0.0%~100.0% (relative to setting frequency)	0.1%	0.0%	○	0B4H
P0-181	Jitter frequency	0.0%~50.0% (Relative to the traverse amplitude)	0.1%	0.0%	○	0B5H
P0-182	Rise time of traverse	0.1~3200.0s	0.1s	15.0s	○	0B6H
P0-183	Fall time of traverse	0.1~3200.0s	0.1s	15.0s	○	0B7H
<b>Serial Communication Setting</b>						
P0-184	Local address	1~31, 33~254:slave address 32:master address(common by inverters)	1	1	○	0B8H
P0-185	Baud rate	0:2400bps 1:4800bps 2:9600bps 3:19200bps 4:38400bps	1	2	○	0B9H
P0-186	Data format	0:1 start bit, 8 data bits, no parity check, 1	1	0	○	0BAH

## List of Function Parameters

Code	Function name	Setting range	Units	Factory setting	Modify	Address
		stop bit. 1: 1 start bit, 8 data bits, even parity check, 1 stop bit 2: 1 start bit, 8 data bits, odd parity check, 1 stop bit				
P0-187	Responson delay	1~150ms	1ms	10ms	○	0BBH
Counter、timer function						
P0-188	Internal counter clock input frequency	1~65535	1	1	○	0BCH
P0-189	Internal counter setting value	1~65535	1	100	○	0BDH
P0-190	Internal counter end value	1~65535	1	200	○	0BEH
P0-191	Internal timer unit	0.01s~655.35s	0.01s	1.00s	○	0BFH
P0-192	Internal timer cycle	1~65535	1	10	○	0C0H
Reserved for functional group						
P0-193	System locked	0~50	1	20	○	0C1H
P0-194	Under-voltage pre-warning judgement value	50.0%~100.0%	0.1%	80.0%	○	0C2H
P0-195	AO1 output bias	0.00~10.00V	0.01	0.00V	○	0C3H
P0-196	AO2 output bias	0.00~10.00V	0.01	0.00V	○	0C4H
P0-197	Keypad poentionmeter min input	0.00~5.00V	0.01V	0.00V	○	0C5H
P0-198	Keypad poentionmeter max input	0.00~5.00V	0.01V	5.00V	○	0C6H
P0-199	filter coefficient of keypad potentiometer	1~12	1	6	○	0C7H
P0-200	VCI input bias	0.00~1.00V	0.01V	0.30V	○	0C8H
P0-201	CCI input bias	0.00~1.00V	0.01V	0.30V	○	0C9H
P0-202	Reserved					0CAH



## List of Function Parameters

Code	Function name	Setting range	Units	Factory setting	Modify	Address
P0-203	Reserved					0CBH
P0-204	Reserved					0CCH
Function Code modify setting						
P0-205	Function code initialization	0: Invalid 1: factory default data 555: user default data 777: Saving current data as user default data 999: Initialize EPP	1	0	×	0CDH
P0-206	Function code writing protection	0: invalid 1: effective	1	0	○	0CEH

### 9.2 P1 function groups (supplier setting function code)

code	function name	setting range	unit	factory setting	modify
P1-000	supplier password	0~65535	1	0	○
P1-001	Model option	0:G (constant torque load) 1:P (fans, pumps load) 2:Z (injection machine special product))	1	0	×
P1-002	Clear working time and fault record	0: Invalid 1: Clear working time and fault record	1	0	○
P1-003	Use time-limit setting (hour)	0 (No use time-limit) ~65535h	1	0	○
P1-004	Reserved				○

### 9.3 d0 function groups (fault information of history)

code	function name	range	units	address
------	---------------	-------	-------	---------

## List of Function Parameters

code	function name	range	units	address
d0-000	Current fault number	0 (no fault) ~18	1	300H
d0-001	Output frequency at current fault	0.00~600.00Hz	0.01Hz	301H
d0-002	Output current at current fault	0.0~2000.0A	0.1A	302H
d0-003	Output voltage at current fault	0.0~500.0V	0.1V	303H
d0-004	DC bus voltage at current fault	0~1000V	1V	304H
d0-005	Latest fault number	0 (no fault) ~18	1	305H
d0-006	Output frequency at latest fault	0.00~600.00Hz	0.01Hz	306H
d0-007	Output current at latest fault	0.0~2000.0A	0.1A	307H
d0-008	Output voltage at latest fault	0.0~500.0V	0.1V	308H
d0-009	DC bus voltage at latest fault	0~1000V	1V	309H
d0-010	Second latest fault number	0 (no fault) ~18	1	30AH
d0-011	Output frequency at second latest fault	0.00~600.00Hz	0.01Hz	30BH
d0-012	Output current at second latest fault	0.0~2000.0A	0.1A	30CH
d0-013	Output voltage at second latest fault	0.0~500.0V	0.1V	30DH
d0-014	DC bus voltage at second latest fault	0~1000V	1V	30EH

### 9.4 d1 function groups (inverter information)

code	function name	range	units	address
d1-000	Software Version number	0~65535	1	400H
d1-001	Software checkout	0~65535	1	401H
d1-002	Machine model setting	0:G (constant torque load) 1:P(fans、 pumps load) 2:Z(injection machine special product)	1	402H
d1-003	Inverter rated power	0.5~1000.0KW	0.1KW	403H
d1-004	Inverter rated voltage	100.0V~1000.0V	0.1V	404H
d1-005	Inverter rated current	1.0~2000.0A	0.1A	405H
d1-006	Inverter accumulate working times (hour)	0~65535h	1h	406H
d1-007	Inverter accumulate working times (second)	0~3600s	1s	407H
d1-008	Inverter Use time-limit (hour)	0 (no use limit-time) ~65535h	1h	408H
d1-009	IPUFIFO (factory test)			409H
d1-010	IPULIMIT (factory test)			40AH

## 9.5 d2 function groups (Inverter running state)

code	function name	range	units	address
d2-000	Inverter running state	Bit0: run sign 0:Stopping 1:Running Bit1:Running direction 0:Forward 1:Reverse Bit2: 0:long-distance control 1:Local keypad control Bit3: 0:No slight fault 1:Slight fault (trip) Bit4: 0:No fault 1:in Faulting (Binary, Bit0 for the lowest bit)	1	500H
d2-001	Setting frequency	0.00~600.00Hz	0.01Hz	501H
d2-002	Output frequency	0.00~600.00Hz	0.01Hz	502H
d2-003	Output current	0.1~2000.0A	0.1A	503H
d2-004	Output voltage	0.1~2000.0V	0.1V	504H
d2-005	DC bus voltage	100~1000V	1V	505H
d2-006	Run rotation speed	0~30000rpm	1rpm	506H
d2-007	Load ratio	0.0~200.0% (Motor rated load)	0.1%	507H
d2-008	Output power	0.00~200.00% (Motor rated power)	0.01%	508H
d2-009	Output torque	0.00~200.00% (Motor rated torque)	0.01%	509H
d2-010	Over-load count	0.0~100.0%	0.1%	50AH
d2-011	Inverter temperature (parts of model reserved)	0~100 °C	1°C	50BH
d2-012	PID closed loop setting	0.00~10.00V	0.01V	50CH
d2-013	PID closed loop feedback	0.00~10.00V	0.01V	50DH

## List of Function Parameters

code	function name	range	units	address
d2-014	Setting frequency of main frequency source X (after calculating gain)	0.00~600.00Hz	0.01Hz	50EH
d2-015	Setting frequency of auxiliary frequency source Y (after calculating gain)	0.00~600.00Hz	0.01Hz	50FH
d2-016	Count value of internal counter	0~65535	1	510H
d2-017	Time value of internal timer	0~65535	1	511H
d2-018	PLC current running step	0~15	1	512H
d2-019	FPIOUT (factory test)			513H
d2-020	UPIOUT (factory test)			514H

## 9.6 d3 function groups (users interface state)

code	function name	range	unit	address
d3-000	Input terminal status 0	LED bit1:X1 0:invalid 1:effective LED bit2:X2 0:invalid 1:effective LED bit3:X3 0:invalid 1:effective LED bit4:X4 0:invalid 1:effective	1	600H
d3-001	Input terminal status 1	LED bit1:X5 0:invalid 1:effective LED bit2:X6 0:invalid 1:effective LED bit3:X7 0:invalid 1:effective LED bit4:X8 0:invalid 1:effective	1	601H

## List of Function Parameters

code	function name	range	unit	address
d3-002	Output terminal status 0	LED bit1:Y1 0:invalid 1:effective LEDbit2:Y2 0:invalid 1:effective LED bit3:MAMC 0:invalid 1:effective	1	602H
d3-003	VCI input voltage	0.00~10.00V	0.01V	603H
d3-004	CCI input voltage	0.00~10.00V	0.01V	604H
d3-005	PULSE Input frequency	0.01~50.00KHz	0.01KHz	605H
d3-006	AO1 output voltage	0.00~10.00V	0.01V	606H
d3-007	A02 output voltage	0.00~10.00V	0.01V	607H
d3-008	AD1C (factory test)			608H
d3-009	AD2C (factory test)			609H
d3-010	AD1IN (factory test)			60AH
d3-011	AD2IN (factory test)			60BH
d3-012	AD3IN (factory test)			60CH

## 10 MODBUS Communication Protocol

This chapter describes the MODBUS communication function. Modbus protocol supports RTU mode

### 10.1 MODBUS Communication Modes

MODBUS communication is made of a master station (PLC or PC) and maximum of 31 slave stations. It communicates in 'point to point' master-slave mode. Master and slave communication (serial communication) is usually the way of slave station respond to the command after master station had communicated. Each master station only with a serial communication between slave. Therefore, each slave station address to be pre-set number, master station through the numbers with the signal communication. It will respond to the specified command sent by the master station.

Interval between each information must be kept as below:




Chart 10-1 Serial Communication diagram

### 10.2 Information format

MODBUS communication adopts the format that master issue the directions and the slave to respond . The message formats(receive/send) are shown in chart 10-2 , according to the different content of instructions (function) , the length of the data also will be changed.

Slave address
Function code
data
Check error

Chart 10-2 Information formats of serial communication

1. Slave address

Inverter address (0~1FHex) .If setting for 0,slave will not respond to the command sent by the master .

2. Function code

Function code is used to specify the command code. See the table below.

Function code (hex)	Function	Instruction info		Response info	
		Min (bit)	Max (bit)	Min (bit)	Max (bit)
03H	To read the contents of storage register	8	8	7	37
08H	Loopback test	8	8	8	8
10H	Multiple storage register read-in	11	41	8	8
80H	Error receiving data from slave			5	5

Chart 10-3 Serial Communication Function Code Description

3. Data

Storage register number (the test code in numbering) and its datas constitute a series of data. According to the contents of the data length the instruction will change.

4. Check error

Using the CRC-16 (cyclic redundancy check, check sum means) to check communication errors.

The result (Check and calculate) is stored in a data(16bit) , its a start value of FFFFH.The data to be sent (slave address, function code and data), a fixed value A001H put together XOR and shift calculation. After the calculation , this data contains a checksum value.

Check and calculation according to the following methods:

- 1) The start value of 16-bit data used to calculate must be set to FFFFH.
- 2) Must be used starting value and slave address to do the XOR calculation.
- 3) The results must be shifted to the right until the overflow bit becomes 1.
- 4) When the overflow bit becomes 1, must use the results of step 3, and a fixed value A001H to do the XOR calculation.
- 5) 8 times shift to calculate after (whenever the overflow bit becomes 1, must be carried out as described in Step 4 to do the XOR calculation), use the results of the previous and the next data (8-bit function code) for XOR operation. The results of this operation must again shifted eight times, when the shift in the overflow bit is 1, the need for a fixed value A001H XOR.
- 6) The data follow the same steps for processing. First deal with high byte, then low byte, until all data are processed.
- 7) The result is a check sum ,contains a high byte and low bytes.

Notice: when adding the checksum in the data frame, the first to add low byte, and then add the high bytes.

## 10.3 Examples of MODBUS Information

### 10.3.1 To read the contents of storage register

A maximum of 16 can be read out the contents of inverter memory registers every time.

First, the instruction information must contain to read out the beginning address of the first register and the amount of register. Response message will contain the contents of the register to be read. Store register content is divided into high 8 bit and low 8 bit, according to number order turn into data within a response message.

Read from the slave 2, the inverter register information 000H, 001H examples as below:



Command information			Response information (normal)			Response information (fault)		
Slave address		02H	Slave address		02H	Slave address		02H
Function code		03H	Function code		03H	Function code		80H
start address		High byte 00H Low byte 00H	Data code		04H	Error code		02H
Number		High byte 00H Low byte 02H	Start storage register		High byte 00H Low byte 00H	CRC-16		High byte 30H Low byte 01H
CRC-16		High byte C4H Low byte 38H	The next storage register		High byte 00H Low byte 00H			
			CRC-16		High byte C9H Low byte 33H			

Chart 10-4 Examples of serial communication

### 10. 3. 2 Test circuit

The instruction information directly as a response message back out. To use master and slave communication testing . Test code, the data can use any value.

Carry out the slave 2 of the inverter loop test of the information shown as below:

Command information			Response information (normal)			Response information (fault)		
Slave address		02H	Slave address		02H	Slave address		02H
Function code		08H	Function code		08H	Function code		80H
Test code		High byte 01H Low byte 02H	Test code		High byte 01H Low byte 02H	Error code		03H
Number		High byte 03H Low byte 04H	Number		High byte 03H Low byte 04H	CRC-16		High byte F1H Low byte C1H
CRC-16		High byte 41H Low byte 37H	CRC-16		High byte 41H Low byte 37H			

Chart 10-5 Examples of serial communication loop testing

### 10. 3. 3 Write into multi-storage register

A maximum of 16 can be written into the contents of inverter memory registers every time.

The specified data are written specified number into the specified storage register . Write into data must in accordance with the number order of register, respectively, according to a high 8 bits, low 8bits order array in the instruction

information.

From PLC to the slave2 of inverter modify 000H、001H information of register,samples as below:

Command information		
Slave address		02H
Function code		10H
Start address	High byte	00H
	Low byte	00H
Number	High byte	00H
	Low byte	02H
data number		04H
Start data	High byte	00H
	Low byte	01H
The next data	High byte	00H
	Low byte	01H
CRC-16	High byte	6CH
	Low byte	EBH
Remarks:Data number=quantity*2		

Response information (normal)		
Slave address		02H
Function code		10H
Start address	High byte	00H
	Low byte	00H
Number	High byte	00H
	Low byte	02H
CRC-16	High byte	51H
	Low byte	9FH

Response information (fault)		
Slave address		02H
Function code		80H
Error code		01H
CRC-16	High byte	31H
	Low byte	C2H

Chart 10-6 write instruction samples of serial communication

### 10. 3. 4 Data saved instruction

After using MODBUS communication, if function code data had been written from the PLC into the inverter, it will be temporarily stored in the data field of inside converter.

Save command mean that RAM function code data is written into the internal EEPROM of inverter (permanent storage ). Write 1 to the register number 0909H mean that had carried out the data storage instruction.

### 10. 3. 5 Broadcast model sent data

When using broadcast model sent data, an instruction can be simultaneously sent to all slaves. The slave address of instruction information must be set to 00H. All slaves have been received from the message, rather than make a response.

## 10. 4 Inverter for slave

When the inverter address for 1 to 31, the slave converter will accept the

following data.

#### 10. 4. 1 Instruction Data

Instruction data as below list. only can be written by using function code10H.

MODBUS register address	Countents	
900H	Bit 0	Run instruction: 1 run; 0 stop
	Bit 1	Direction instruction: 1 reverse;0 forward
	Bit 2	JOG instruction: 1 JOG; 0 stop
	Bit 3	Reset instruction: 1 fault reset; 0 no
	Bit 4~F	reserved
901H	Frequency instruction	
902H	PID setting value	
903H~908H	reserved	
909H	Save instruction: 1 parameter data save to EEPROM	
Remarks: Bit 0 for the lowest bit		

Chart 10-7 Data definition of communication instruction

#### 10. 4. 2 Monitoring Data

The function code of d0, d1, d2, d3 function groups can be used as surveillance data, use the 03H function Code to read the content. Each function code MODBUS register address see the function list. Transfer data to an integer, pay attention to the unit of each function code.

#### 10. 4. 3 Set Data

The function code of P0 function group can be modified, use the 10H function code is written. MODBUS register address of all function codes see the function list. Transfer data to an integer, pay attention to the unit of each

function code.

### 10. 4. 4 Test Data

When Looping test, receive test data of 08H function code, and respond reply.

### 10. 5 Inverter for master

When the address of inverter is 32, the inverter will act as the master converter to send the following broadcast data. At this time the master inverter in currently running to send run and stop instructions. Setting frequency is sent as frequency instruction. MODBUS register address is 900H and 901H.

The transmission frequency of master inverter command is 50.0Hz, set the forward running information as shown below.

MODBUS register address	Contents	
900H	Bit0	Run command 1:run; 0:stop
	Bit1	Direction command 1:reverse; 0:forward
	Bit2	Reserved
	Bit 3~F	Reserved
901H	Frequency command	
Remarks: Bit0 is the lowest bit		

Command information		
Slave address		00H
Function code		10H
Start address	High byte	09H
	Low byte	00H
Number	High byte	00H
	Low byte	02H
data number		04H
Start data	High byte	00H
	Low byte	01H
The next data	High byte	13H
	Low byte	88H
CRC-16	High byte	C1H
	Low byte	95H

Chart 10-8 serial command samples of master inverter

### 10. 6 MODBUS Communication Error Codes

When the slave inverter receives the data is incorrect, it will respond to function code for the data frame of 80H , see the table below:

Error codes	Contents
01H	In running, not allowed to access.

02H	Data overflow 1. MODBUS address exceed range 2. The data to write exceed the range 3. The data to write exceed the upper-lower limit range of data comments.
03H	Function code overflow

Chart 10-9 Error codes of serial communication

### 10.7 Back-check of no response fault for slave

In the following conditions, slaves ignore the master command information, and do not send the response information.

1. Had checked up the send error in instruction information( exceed melody、frame、checkout、CRC-16).
2. It is different that slave address of instruction information and slave address of inverter side.
3. When time intervals of data and data of composing information exceed the length(24 bit).

---

## Chart Index

Chart 2-1 description of nameplate.....	11
Chart 2-2 power description of model.....	11
Chart 2-3 Naming rule.....	12
Chart 2-4 220V series description.....	13
Chart 2-5 380V series description.....	14
Chart 2-6 technology criterion.....	16
Chart 2-7 reactor option description.....	17
Chart 2-8 Braking Resistor Selection Guide.....	18
Chart 2-9 wiring at braking resistor[less than 30kW] ..	19
Chart 2-10 wiring at braking resistor [above 37kW] .....	19
Chart 2-11 wiring at the signal board of injection machine .....	20
Chart 3-1 safe space.....	22
Chart 3-2 External Dimension(0.4~5.5KW) .....	22
Chart 3-3 External Dimension (7.5~15KW) .....	23
Chart 3-4 External Dimension (18.5~200KW) .....	23
Chart 3-5 External Dimension (220~560KW) .....	24
Chart 3-6 220V External Dimension.....	24
Chart 3-7 380V External Dimension.....	25
Chart 4-1 connection of periperal devices.....	26
Chart 4-2 wiring diagram(A100T3R7G~A100T030G) .....	27
Chart 4-3 wiring diagram(A100T037G~A100T055G) .....	28
Chart 4-4 wiring diagram(A100T075G~A100T280G) .....	29
Chart 4-5 Main circuit terminals.....	29
Chart 4-6 Description of main circuit symbol.....	30
Chart 4-7 control board layout.....	31

## Chart Index

---

Chart 4-8 Control circuit terminals layout.....	31
Chart 4-9 control circuit terminals description.....	33
Chart 4-10 wiring diagram of analog input.....	34
Chart 4-11 wiring diagram of NPN transistor input.....	34
Chart 4-12 PNP wiring diagram of NPN transistor input..	35
Chart 4-13 wiring diagram of digital output.....	35
Chart 4-14 Jumpers on control board.....	36
Chart 5-1 Keypad schematic diaagram.....	37
Chart 5-2 Key function description.....	38
Chart 5-3 run state indicator light description.....	38
Chart 5-4 unit indicator light description.....	39
Chart 5-5 Description of the inverter operation status .	40
Chart 5-6 fast-monitoring diagram.....	40
Chart 5-7 Function code setting diagram.....	40
Chart 5-8 Information query diagram.....	41
Chart 5-9 Quick debugging flowchart.....	43
Chart 6-1 switch description of command source.....	45
Chart 6-2 PRI description of running and JOG.....	45
Chart 6-3 selection terminals description of frequency source .....	45
Chart 6-4 PRI description of running directions control	48
Chart 6-5 Setting reference of carrier frequency.....	49
Chart 6-6 V/F curve chart.....	51
Chart 6-7 Diagram of two-wire run mode.....	56
Chart 6-8 3-wire run mode diagram.....	57
Chart 6-9 Analog or pulse corresponding frequency setting curve.....	58

## Chart Index

---

Chart 6-10 Analog Output Gain diagram.....	61
Chart 6-11 FWD/REV dead time diagram.....	63
Chart 6-12 Acc/Dec time of terminals selection.....	64
Chart 6-13 skip frequency run diagram.....	66
Chart 6-14 description of frequency arrive detecting range .....	67
Chart 6-15 description of FDT level.....	67
Chart 6-16 simple "one drag two function" description....	68
Chart 6-17 Diagram of over-current protection when lose speed .....	70
Chart 6-18 Diagram of lower frequency limit current....	71
Chart 6-19 Diagram of multi-stage speed mode 0.....	74
Chart 6-20 Diagram of multi-step model.....	74
Chart 6-21 PLC Acc/Dec time selection.....	77
Chart 6-22 Traverse frequency run diagram.....	81
Chart 6-23 Counting function diagram.....	83
Chart 6-24 Timing function diagram.....	83
Chart 7-1 fault and trouble shooting.....	89
Chart 8-1 Inspect the inverter periodically.....	91
Chart 10-1 Serial Communication diagram.....	113
Chart 10-2 Information formats of serial communication	114
Chart 10-3 Serial Communication Function Code Description .....	114
Chart 10-4 Examples of serial communication.....	116
Chart 10-5 Examples of serial communication loop testing .....	116
Chart 10-6 write instruction samples of serial communication	



..... 117  
Chart 10-7 Data definition of communication instruction 118  
Chart 10-8 serial command samples of master inverter . 119  
Chart 10-9 Error codes of serial communication ..... 120

**SHENZHEN NOWFOREVER ELECTRONICS TECHNOLOGY CO.,LTD**

---

In order to improve our products constantly, we remain the power of designs modified .

2010-03-08